

Raven Rate Control Module (RCM) Operation Manual

016-0171-637 Rev. G

7/2025

E51233



Calibration Reference Sheet	v
Unit Definitions and Conversions	vi
Unit of Measure Definitions	vi
Unit of Measure Conversions	vi
Chapter 1 Important Information	1
Safety	1
Agricultural Chemical Safety	4
Hydraulic Safety	4
Electrical Safety	5
Machine Safety Systems	6
Recommendations and Best Practices	6
Hose Routing	6
Harness Routing	6
Chapter 2 Introduction	9
Raven Rate Control Module™ Features	10
Direct Injection	10
Multiple UT Settings	10
Machine Types	11
Care and Use	12
Feature Unlocks	13
Compliance	14
ICASA	14
Updates	14
Chapter 3 Liquid Operation	15
Liquid Machine List	15
Liquid Fertilizer Configuration	16
Liquid Run Page Overview	24
Product Tabs	24
Current Product Run Screen	24
Main	26
Setup	26
Totals	28
Diagnostics	28
Auxiliary Drivers	28
Chapter 4 Anhydrous Ammonia (NH₃) Operation	31
NH ₃ Machine List	31
Raven AccuFlow HP™ Plus Systems	31
Overview of Operation	31
Pump Fault	32
Delta Pressure Sensor / Vapor Monitor	33

NH3 Configuration	33
NH3 Run Page Overview	42
Product Tabs	42
Current Product Run Screen	42
Run Page Overview	42
Main	44
Setup	44
Totals	45
Diagnostics	45
Auxiliary Drivers	46
Chapter 5 Spreader Operation	47
Spreader Machine List	47
Spreader Configuration	50
Manure/Litter Configuration	63
Dynamic Calibration	64
Density Adjustment Frequency	64
Adjustment Sensitivity	65
Clean Out Setup	65
Clean out Mode	65
Litter/Manure Operation Tips	66
Spreader Run Page Overview	68
Product Tabs	68
Current Product Run Screen	68
Run Page Overview	68
Main	71
Setup	71
Totals	73
Diagnostics	73
Manure/Litter Spreader Configuration and Settings	73
Clean Out Setup	73
Dynamic Calibration	74
Chapter 6 Air Cart Operation	77
Machine Types	77
Air Cart Configuration	80
Air Cart Run Page Overview	91
Product Tabs	91
Current Product Run Screen	92
Main	94
Setup	94
Totals	95
Diagnostics	96
Auxiliary Drivers	96

Chapter 7	Planter Operation	97
Planter Machine List		97
Planter Setup		98
Section Controlled Planter Setup		98
Seed Rate Control with Clutches Planter Setup		99
Seed Rate Control without Clutches Plater Setup		107
Planter Run Page Overview		116
Product Tabs		117
Current Product Run Screen		117
Main		119
Setup		119
Totals		121
Diagnostics		122
Auxiliary Drivers		122
Chapter 8	Stand alone Scale Operation	123
Scale machine List		123
Stand Alone Scale Operation		123
Scale Run Page Overview		125
Scale Screen		125
Current Product Run Screen		126
Main		127
Setup		127
Totals		129
Diagnostics		129
Auxiliary Assignments		130
Chapter 9	Precision Farming	131
Chapter 10	Troubleshooting	137
Accessing System Information		137
General Troubleshooting		139
Tests		140
Nozzle Flow Check		142
Rinse Cycle		143
Control/Section Test		143
Control Valve Test		144
Calibrate PWM Limits		144
Energize System		145
Bleed System Test		146
Spreader/Air Cart Check		147
Bin/Tank Cleanout		148
Demonstration Mode		148
Diagnostic Loop back Test		149
Diagnostic LEDs		152

Table of Contents

Outputs Table - Single Product	154
Outputs Table - Multiple Products	156
Inputs Table - Single Product	157
Inputs Table - Multiple Product	159
Chapter 11 Diagnostics Trouble Codes.....	161
Accessing diagnostic Trouble Codes	161
Diagnostic trouble codes (DTC)	161
Appendix A Calibration Values.....	171
Section Widths	171
Target Rate Calibration	171
Appendix B Settings and Help Screen Terminology.....	173

CALIBRATION REFERENCE SHEET

Record settings and calibration values used when programming the system in the fields below and keep this sheet for future reference.

GENERAL IMPLEMENT INFORMATION

UNITS	US (Acres)	SI (Hectares)	Nozzle Spacing	
Speed Cal				

Section Widths (Boom Cal)			
1.	5.	9.	13.
2.	6.	10.	14.
3.	7.	11.	15.
4.	8.	12.	16.

TANK FILL SETTINGS

Tank Capacity		Low Tank Limit	
Fill Flow Meter Cal		Units	

PRODUCT CONTROL SETTINGS

Min. Pump PWM		Max. Pump PWM	
Standby Pump PWM		Pump PWM Frequency	
Minimum Nozzle PWM		Meter Cal	
Units		Response Rate	
Deadband			

PRESSURE SETTINGS

Min. Pressure		Max. Pressure	
---------------	--	---------------	--

UNIT DEFINITIONS AND CONVERSIONS

UNIT OF MEASURE DEFINITIONS

Abbreviation	Definition
GPM	Gallons per Minute
lit/min	Liters per Minute
dl/min	Deciliters per Minute
PSI	Pounds per Square Inch
kPa	Kilopascal
GPA	Gallons per Acre
lit/ha	Liters per Hectare
ml/ha	Milliliters per Hectare
GPK	Gallons per 1,000 Square Feet
mm	Millimeters
cm	Centimeters

Abbreviation	Definition
dm	Decimeters
m	Meter
MPH	Miles per Hour
km	Kilometers
km/h	Kilometers per Hour
US	Volume per Acre
SI	Volume per Hectare
TU	Volume per 1,000 Square Feet
[]	Metric Numbers
lb/acre	Pounds per Acre
kg/ha	Kilograms per Hectare

UNIT OF MEASURE CONVERSIONS

To convert the meter cal value into the selected unit of measure, divide the original number printed on the flow meter label by the desired conversion value.

Fluid Ounces Conversion Formula	Liters Conversion Formula	Pounds Conversion Formula
$\frac{\text{Original Meter Cal}}{128}$	$\frac{\text{Original Meter Cal}}{3.785}$	$\frac{\text{Original Meter Cal}}{\text{Weight of One Gallon of}}$

Liquid	Length
<ul style="list-style-type: none"> • 1 U.S. gallon = 128 fluid ounces • 1 U.S. gallon = 3.785 liters • 1 U.S. gallon = 0.83267 imperial gallons • 1 U.S. gallon = 8.34 pounds (water) • 1 U.S. gallon = 10.67 pounds (28% N) • 1 U.S. gallon = 11.06 pounds (32% N) • 1 U.S. gallon = 11.65 pounds (10-34-0) 	<ul style="list-style-type: none"> • 1 millimeter (mm) = 0.039 inches • 1 centimeter (cm) = 0.393 inches • 1 meter (m) = 3.281 feet • 1 kilometer (km) = 0.621 miles • 1 inch = 25.4 mm or 2.54 cm • 1 mile = 1.609 km
Area	Pressure
<ul style="list-style-type: none"> • 1 square meter = 10.764 square feet • 1 hectare = 2.471 acres or 10,000 square meters • 1 acre = 0.405 hectares or 43,560 square feet • 1 square mile = 640 acres or 258.9 hectares 	<ul style="list-style-type: none"> • 1 psi = 6.89 kPa • 1 kPa = 0.145 psi

SAFETY

NOTICE

Follow the operation and safety instructions included with the implement and/or controller and read this manual carefully before installing or operating this Raven system.

- Follow all safety information presented within this manual. Review implement operation with your local dealer.
- Contact a local Raven dealer for assistance with any portion of the installation, service, or operation of Raven equipment.
- Follow all safety labels affixed to system components. Be sure to keep safety labels in good condition and replace any missing or damaged labels. Contact a local Raven dealer to obtain replacements for safety labels.

Observe the following safety measures when operating the implement after installing this Raven system:

- Do not operate this Raven system or any agricultural equipment while under the influence of alcohol or an illegal substance.
- Be alert and aware of surroundings and remain in the operator seat at all times when operating this Raven system.
 - Do not operate the implement on any public road with this Raven system enabled.
 - Disable this Raven system before exiting the operator seat.
 - Determine and remain a safe working distance from obstacles and bystanders. The operator is responsible for disabling the system when a safe working distance has diminished.
 - Disable this Raven system prior to starting any maintenance work on the implement or components of this Raven system.
- Do not attempt to modify or lengthen any of the system control cables. Extension cables are available from a local Raven dealer.

 **DANGER**

Anhydrous ammonia (NH_3) under pressure. NH_3 can cause severe burning, blindness, sickness, or death. Understand all safety instructions and warnings before operating or servicing equipment.

- Review the properties of NH_3 and the procedures for safe handling, and use with your NH_3 supplier.
 - Contact your NH_3 supplier or the appropriate agricultural department for training on handling, transporting, transferring, and applying NH_3 . Training should be completed at least every three years.
 - Always wear appropriate personal protective equipment (PPE) when installing, inspecting, servicing, and operating the NH_3 system. Appropriate PPE includes, but is not limited to:
 - Liquid proof gauntlet-style gloves impervious to NH_3 .
 - Long sleeved shirt and long pants or protective suit.
 - Indirect vent chemical splash goggles or indirect vent chemical splash goggles with full-face shield.
 - Check operation of system components (e.g. valves, temperature and pressure gages) prior to charging the system with NH_3 .
 - Seek immediate medical attention if symptoms of illness occur during or shortly after use of NH_3 products.
- Use extreme caution when servicing or maintaining a system that has previously been pressurized with NH_3 .
 - Keep a source of clean water (at least five gallons) readily available while working with NH_3 . This source should be in addition to, and separate from, the water source on the nurse tank.
 - Read and follow instructions provided with the application system to properly discharge NH_3 before performing service or maintenance.
 - Pressure gauges can fail, become plugged, or display incorrect pressure. Slowly bleed pressure from a previously charged system by opening valves slightly. Allow pressure to discharge for an extended period of time. Treat every section where NH_3 can be trapped as though it is pressurized.
 - Thoroughly bleed all system lines and disconnect the nurse tank hose to remove NH_3 from the system before transporting the system or beginning service or maintenance. Liquid NH_3 can absorb heat from surroundings and re-pressurize the system. Any bleed valves that are opened to relieve pressure should remain open while transporting the system or maintenance is being performed.
 - Stand 'up wind' when working around NH_3 and related equipment. Never work on NH_3 equipment in confined spaces. Always keep NH_3 equipment away from buildings, livestock, and other people.
 - Before each day's use:
 - Visually inspect all system plumbing components for functionality, excessive wear, and damage.
 - Some components may have recommended "replace by" dates or maximum service periods regardless of visual condition.
 - Replace individual components if excessively worn, visually damaged, or non-functioning, as recommended by the component manufacturer, or as required by regulation, whichever is sooner.
 - Test excess flow valves and document the date and result of tests. Replace any components that do not pass inspection as needed.
 - Never uncouple an NH_3 applicator or intermediate towing vehicle without appropriate parking stands, wheel chocks, or other braking systems if a nurse take wagon is attached.
 - Immediately evacuate the area in case of leak or accidental release of NH_3 . Contact your local fire department, and identify sources of clean water on the unit.

- In case of exposure, flush exposed skin and eyes immediately with large quantities of water for at least 15 minutes and seek immediate medical attention.
- NH₃ can be harmful to the environment if not used properly.
 - Follow all federal, state, and local regulations regarding the handling and use of NH₃.
- Only NH₃ harness systems, control systems, and on/off valves approved by Raven Industries are recommended for use with NH₃ products. Raven shall not be liable for any damages and this warranty shall not cover defects from:
 - The use of a system with a harness not approved by Raven.
 - The use of a control system not approved by Raven.
 - The use of an on/off valve not approved by Raven.
 - The use of the system in a manner that is inconsistent with the instructions.
 - Unauthorized modification to the system or products used in the system.
 - Follow the best practices for installing and routing hoses provided in *Recommendations and Best Practices* section on page 6.

 **WARNING**

AGRICULTURAL CHEMICAL SAFETY

Follow all federal, state, and local regulations regarding the handling, use, and disposal of agricultural chemicals, products, and containers. Triple-rinse and puncture or crush empty containers before properly disposing of them. Contact a local environmental agency or recycling center for additional information.

- Always follow safety labels and instructions provided by the chemical manufacturer or supplier.
- Always wear appropriate personal protective equipment as recommended by the chemical and/or equipment manufacturer.
- When storing unused agricultural chemicals:
 - Store agricultural chemicals in the original container and do not transfer chemicals to unmarked containers or containers used for food or drink.
 - Store chemicals in a secure, locked area away from human and livestock food.
 - Keep children away from chemical storage areas.
- Fill, flush, calibrate, and decontaminate chemical application systems in an area where runoff will not reach ponds, lakes, streams, livestock areas, gardens, or populated areas.
- Follow all label instructions for chemical mixing, handling, and disposal.
- Avoid direct contact with agricultural chemicals or inhaling chemical dust or spray particulate. Seek immediate medical attention if symptoms of illness occur during, or soon after, use of agricultural chemicals or products.
- After handling or applying agricultural chemicals:
 - Thoroughly wash hands and face after using agricultural chemicals and before eating, drinking, or using the restroom.
 - Thoroughly flush or rinse equipment used to mix, transfer, or apply chemicals with water after use or before servicing any component of the application system.

HYDRAULIC SAFETY

When installing or servicing a hydraulic system or hydraulic components, be aware that hydraulic fluid may be extremely hot and under high pressure. Caution must be exercised.

- Always wear appropriate personal protective equipment when installing or servicing hydraulic systems.
- Never attempt to open or work on a hydraulic system with the implement running.
- Any work performed on the hydraulic system must be done in accordance with the machine manufacturer's approved maintenance instructions.
- Care should always be taken when servicing or opening a system that has been pressurized.
- The implement or machine must remain stationary and switched off with booms or implement sections unfolded and supported during installation or maintenance.
- Take precautions to prevent foreign material or contaminants from being introduced into the implement hydraulic system. Contaminants that are able to bypass the hydraulic filtration system will reduce performance and may damage hydraulic components.
- Stand clear of the implement when starting the system for the first time after installing or servicing hydraulic components in case a hose has not been properly connected or tightened.

 **CAUTION****ELECTRICAL SAFETY**

- Always verify that power leads are connected to the correct polarity as marked. Reversing the power leads could cause severe damage to the Raven system or other components.
- To prevent personal injury or fire, replace defective or blown fuses with only fuses of the same type and amperage.
- Do not connect the power leads to the battery until all system components are mounted and all electrical connections are completed.
- Always start the machine before initializing this Raven system to prevent power surges or peak voltage.
- To avoid tripping and entanglement hazards, route cables and harnesses away from walkways, steps, grab bars, and other areas used by the operator or service personnel when operating or servicing the equipment.

MACHINE SAFETY SYSTEMS

- Use all provided safety systems on the machine when operating the machine with the Raven system.
- Seat belts and restraints must be used when an operator is in the cab.
- Do not disable any machine-provided safety systems, including but not limited to audible alarms, alarm lights, etc.

RECOMMENDATIONS AND BEST PRACTICES

HOSE ROUTING

The word “hose” is used to describe any flexible, fluid carrying components. Use the following guidelines and recommendations when connecting and routing hoses while installing or maintaining this Raven system:

- Leave protective caps/covers over hose ends until connecting the end into the hydraulic system to help prevent contaminants from entering the system.
- Follow existing hose runs already routed on the implement as much as possible. Proper hose routing should:
 - Secure hoses and prevent hoses from hanging below the implement.
 - Provide sufficient clearance from moving components and operational zones around shafts; universal joints and suspension components; pulleys, gears, belts, and chains; moving linkages, cylinders, articulation joints, etc.
 - Protect hoses from field debris and surrounding hazards (e.g. tree limbs, fence posts, crop stubble, dirt clumps or rocks that may fall or be thrown by the implement).
 - Protect hoses from sharp bends, twisting, or flexing over short distances and normal implement operation.
 - Ensure sufficient length for free movement of the implement during normal operation and prevent pulling, pinching, catching, or rubbing, especially in articulation and pivot points. Clamp hoses securely to force controlled movement of the hose.
 - Avoid abrasive surfaces and sharp edges such as sheared or flame cut corners, fastener threads or cap screw heads, hose clamp ends, etc.
 - Avoid areas where the operator or service personnel might step or use as a grab bar.
- Do not connect, affix, or allow hoses to come into contact with components with high vibration forces, hot surfaces, or components carrying hot fluids beyond the temperature rating of hose components.
 - Hoses should be protected or shielded if routing requires the hose to be exposed to conditions beyond hose component specifications.
- Avoid routing hoses in areas where damage may occur due to build up of material (e.g. dirt, mud, snow, ice, etc.).

HARNES ROUTING

The word “harness” is used to describe any electrical cables and leads, both bundled and unbundled. Use the following guidelines and recommendations when connecting and routing harnesses while installing or maintaining this Raven system:

- Leave protective caps/covers over harness connectors until needed to avoid dirt and moisture from contaminating electrical circuits.
- Secure the harness to the frame or solid structural members at least every 12 in [30 cm].
- Follow existing harness runs already routed on the implement as much as possible. Proper harness routing should:

- Secure harnessing and prevent the harness from hanging below the implement.
- Provide sufficient clearance from moving components and operational zones around shafts; universal joints and suspension components; pulleys, gears, belts, and chains; moving linkages, cylinders, articulation joints, etc.
- Protect harnessing from field debris and surrounding hazards (e.g. tree limbs, fence posts, crop stubble, dirt clumps or rocks that may fall or be thrown by the implement).
- Protect harnessing from sharp bends, twisting, or flexing over short distances and normal implement operation.
- Connectors and splices should not be located at bending points or in harness sections that move.
- Ensure sufficient length for free movement of the implement during normal operation and prevent pulling, pinching, catching, or rubbing, especially in articulation and pivot points. Clamp harnessing securely to force controlled movement of the harness.
- Avoid abrasive surfaces and sharp edges such as sheared or flame cut corners, fastener threads or cap screw heads, hose clamp ends, etc.
- Do not connect, affix, or allow harnessing to come into contact with components with high vibration forces, hot surfaces, or components carrying hot fluids beyond the temperature rating of harness components.
 - Harnessing should be protected or shielded if routing requires the hose to be exposed to conditions beyond harnessing component specifications.
- Avoid routing harnesses in areas where damage may occur due to build up of material (e.g. dirt, mud, snow, ice, etc.).
- Avoid routing harnesses in areas where the operator or service personnel might step or use as a grab bar.

IMPORTANT: Avoid applying direct spray or pressure washing of electrical components and connections. High pressure streams and sprays can penetrate seals, cause corrosion, or otherwise damage electrical components. When performing maintenance:

- Inspect electrical components and connectors for corrosion, damaged pins or housings, etc. Repair or replace components or harnessing as necessary.
- Ensure connectors are kept clean and dry. Apply dielectric grease to the sealing surfaces of all connections exposed to moisture, dirt, debris, and other contaminants. Repair or replace harnessing as necessary.
- Clean electrical components with pressurized air, aerosol electrical cleaning agent, or low pressure rinse.
- Remove visible surface water from electrical components and connections using pressurized air or an aerosol cleaning agent. Allow components to dry thoroughly before reconnecting cables.

The Raven Rate Control Module (RCM) is a multi-product application control system built on an ISOBUS platform. The Raven Rate Controller Module is designed to provide a machine operator the ability to simultaneously monitor and control five product applications such as liquid, granular, NH₃, and direct injection via ISOBUS Universal Terminal (UT) and task control for as-applied documentation, prescription rate, and section control.

This document is intended to provide information regarding the following aspects of the Raven Rate Control Module:

- Initial Setup and Navigation
- Calibration
- Raven Rate Control Module System Operation
- Raven Rate Control Module Alarms
- Updating Raven Rate Control Module Components

NOTE: Prior to using the Raven Rate Control Module control features with any UT display, the Raven Rate Control Module electronic control unit (ECU) must be calibrated for the control system. Refer to Chapter 3, *ISOBUS System Calibration*, for assistance with completing the initial calibration wizard.

This manual assumes that the required control hardware is already installed on supported equipment and is properly connected. Contact a local Raven dealer for additional information on supported equipment configurations.

RAVEN RATE CONTROL MODULE™ FEATURES

DIRECT INJECTION

The Raven Sidekick™ Pro ICD provides for an optimal user experience by allowing control of direct injection through the Raven Rate Control Module interface. By using a separate injection module or tank, the system eliminates mixing chemicals in the tank, reduces chemical waste, and simplifies equipment care and maintenance. Connect up to four injection systems to the Viper 4 and ISOBUS to control the whole system through the Raven Rate Control Module user interface screens on the virtual terminal. Purchase a high flow injection system to control a wide range of chemical flow rates from 5 - 200 oz/min. Purchase a low flow injection system to provide chemical flow rates from 1 - 40 oz/min. Refer to the Sidekick™ ICD Manual for additional information on high and low flow injection systems.

Contact a local Raven dealer for additional details on direct injection using Sidekick Pro™ with Raven Rate Control.

MULTIPLE UT SETTINGS

When an RCM is used in a system with more than one UT (universal terminal), the RCM can be assigned a primary UT.

FIGURE 1. Set Primary UT Menu



MACHINE TYPES

The Raven Rate Control Module can be used with:

TABLE 1. RCM Machine List

Machine Type	Application Mode	Application Type
Self-Propelled Sprayer Pull-Behind Sprayer	Liquid Liquid Tiered (Direct) Liquid Tiered (External) Liquid Constant Flow	Liquid
Liquid Fertilizer Tool	Liquid Liquid Tiered (Direct) Liquid Tiered (External) Liquid Constant Flow Liquid Slurry Dragline Liquid Slurry	Liquid
NH3 Tool	NH3 NH3 HP+	NH3
Self-Propelled Spreader Pull-Behind Spreader	Dry Manure/Litter Granular Full Width Granular RPM Compensated Granular RPM Maintained Granular Split Belt Granular Dual Control Valve	Granular Fertilizer Granular Seed
Air Cart Generic	Liquid Granular Full Width Granular RPM Compensated Granular RPM Maintained Granular Split Belt Granular Dual Control Valve Granular Meter Per Section	Liquid Granular
Planter	Planter Section Control Seed Rate Control (/W Clutches) See Rate Control (no Clutches)	NA
Scale	NA	NA

CARE AND USE

Always follow equipment manufacturer's recommended maintenance procedures for storing equipment. The following maintenance procedures are generally recommended for storing equipment with the Raven Rate Control Module:

1. Empty product from the chemical supply tank and flush the application system with water.
2. Remove hardened chemical residues or build up by flushing the system with:
 - a. kerosene or fuel oil if the last product applied was petroleum based.
 - b. soap and water if the last product applied was water based.
3. Prime the system plumbing with a 50% water and automotive antifreeze mixture to prevent freezing of components. Freezing will result in damage to the system and other plumbing components on the system.

FEATURE UNLOCKS

Every RCM comes with different levels of unlocks. To purchase additional unlocks, navigate to portal.ravenprecision.com and purchase the desired unlocks. The table below lists unlock levels:

TABLE 2. RCM Unlocks

Level	ECU P/N	Features
0	063-0173-940	<ul style="list-style-type: none"> • Ground drive/no control valve product monitoring/no task controller interface (section control, as applied documentation) • Generic single channel scale/no application control
1	063-0173-941	<ul style="list-style-type: none"> • Single product control with section shut-off • Liquid NH₃(HP+)/Granular • Dual valve control (no support for multiple rate control sections) • Spinner/fan control (two channel) • No scale support (product or general purpose) with products enabled. • Multiple Sidekick ICD control supported • Task controller support for ground drive transmission (section control, as-applied documentation) • Planter section control - up to 16 sections/clutches • Generic four channel scale/no application control
2	063-0173-756	<ul style="list-style-type: none"> • Multi-product application control (up to five products) • Scale support in conjunction with application control • Tiered boom (two tiers) • Multiple rate control sections (with or without VRA capability) • Planter section control - up to 32 sections/clutches
3	063-0173-953	<ul style="list-style-type: none"> • Granular Meter per Section • Planter Seed Rate Control (with clutches) • Planter Seed Rate Control (without clutches) • Manure/Litter spreader
3 Stack Tiered Boom	077-0180-202	<ul style="list-style-type: none"> • Enable for three stacks or tiers (A, B, and C or a combination thereof).
3 Stack Blockage Monitoring	077-0180-201	<ul style="list-style-type: none"> • Enable interfacing to a third party blockage monitoring system to provide section awareness from RCM.

COMPLIANCE

The BLUETOOTH® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Raven Industries, Inc. is under license. Other trademarks and trade names are those of their respective owners.

ICASA



TA 2021-0343
APPROVED

UPDATES

Updates for Raven manuals as well as software updates for Raven consoles, and product controllers are available at the Applied Technology Division web site:

<https://portal.ravenprecision.com>

The Raven Service Tool and a laptop PC are required to perform software updates of the Raven Rate Control Module. Refer to the Raven Service Tool Operation manual for additional assistance with updating the Raven Rate Control Module.

Sign up for e-mail alerts to receive notifications when updates for your Raven products are available on the Raven web site.

At Raven Industries, we strive to make your experience with our products as rewarding as possible. One way to improve this experience is to provide us with feedback on this manual.

Your feedback will help shape the future of our product documentation and the overall service we provide. We appreciate the opportunity to see ourselves as our customers see us and are eager to gather ideas on how we have been helping or how we can do better.

To serve you best, please send an email with the following information to

techwriting@ravenind.com

- Raven Rate Control Module (RCM) Operation Manual
- 016-0171-637 Rev. G
- Any comments or feedback (include chapter or page numbers if applicable).
- Let us know how long have you been using this or other Raven products.

We will not share your email or any information you provide with anyone else. Your feedback is valued and extremely important to us.

Thank you for your time.

CHAPTER

LIQUID OPERATION

3

LIQUID MACHINE LIST

TABLE 1. RCM Liquid Machine List

Machine Type	Application Type	Application Mode	Application Mode Uses
<ul style="list-style-type: none"> • Self-Propelled Sprayer • Pull-Behind Sprayer 	• Liquid	Liquid	Conventional Liquid application. Application rate is entered and documented as gallons/acre (liters/hectare).
		Liquid Tiered (Direct)	Tiered boom liquid application in which two-way boom valves are controlled directly by signals provided by the rate controller.
		Liquid Tiered (External)	Tiered boom liquid application in which two-way boom valves are controlled by an external module using section and tier signals by the rate controller.
		Liquid Constant Flow	Single boom liquid application using three-way boom valves that divert flow back to tank in the off position.
		Tiered Boom - Low Side Drive	The controller will activate tiers by supplying a ground (earth) signal that can be connected to the return (low side) of the valve bank. The signal will float when the tier is off, causing the connected valve bank to turn off.
<ul style="list-style-type: none"> • Liquid Fertilizer Tool 	• Liquid	Liquid Slurry Dragline	Liquid application for products that do not have a control valve and require a large application rate like liquid manure.
		Liquid Slurry	Conventional liquid application for products that require a large application rate like liquid manure.

LIQUID FERTILIZER CONFIGURATION

This section provides a liquid fertilizer configuration example. Depending on machine configuration the following screens will vary.

1. Select the desired sprayer type from the Machine Type drop down.

FIGURE 1. Name Profile

2. Enter a name for the profile in the Profile Name field.
3. Select the application width.
4. Press Next.
5. Select the appropriate ECU # from the drop down. The lower the ECU number, the higher priority the ECU will have when paired with an injection system.

FIGURE 2. Setup System

ECU S/N	ECU #	Number of Products
RCM-47	2	1 ?


6. Press Next.
7. Select the Application Mode from the drop down.

FIGURE 3. Setup Application Type



8. Press Next.
9. On the Setup Sections screen, enter the Number of Sections and select the Section Valve Type.

FIGURE 4. Setup Sections



10. If desired, select the Equal Width Sections and Fence Rows Enable check boxes.
11. Press Next.
12. Select the fence row driver for each fence row (if selected earlier).


FIGURE 5. Setup Fence Row Drivers



13. Press Next.

14. Review the section width information on the Setup Section Width screen.

FIGURE 6. Setup Section Width



15. If needed, adjust the section widths.

16. Press Next.

17. If desired, configure auxiliary drivers on the Setup Auxiliary Drivers screen. Auxiliary drivers are additional switches that provide a 12V signal to a device.

FIGURE 7. Setup Auxiliary Drivers



18. Press Next.
19. Review the information on the Section Summary screen.

FIGURE 8. Section Summary



20. Press Next.
21. Select the appropriate pressure sensors configuration for each pressure sensor.


FIGURE 9. Setup Pressure Sensors



22. Press Next.

23. If desired, set the Min and Max pressures and select the Alarm? check box for each pressure sensor.

FIGURE 10. Setup Pressure Alarms



24. Press Next.

25. If an agitator is installed and will be used, select the Agitator Installed checkbox and configure the Agitator Duty Cycle. Also select the Flow Return Installed checkbox if desired.

FIGURE 11. Setup Auxiliary Functions

Setup Auxiliary Functions

Agitator Installed ?

Agitator Duty Cycle (s) 10

Flow Return Installed

RAVEN

26. Press Next.

27. On the Setup Control Valve page, configure the information for the product. This includes selecting the Control Valve Type, Valve Response Rate, and Control Deadband.

FIGURE 12. Setup Control Valve

Setup Control Valve

Product 1 Liquid ?

Control Valve Type Standard

Valve Response Rate (1-100) 50

Control Deadband (s) 3

Valve Delay (seconds) 0.0

Valve Advance (seconds) 0.0

Control Effort (s) 35

RAVEN

28. Press Next.

29. Configure the rate sensor for the product by entering the Flow Meter Calibration and selecting the Flow Meter Pulses/Units.

FIGURE 13. Setup Rate Sensors

Setup Rate Sensor

Product 1 Liquid ?

Flowmeter Calibration: 780

Flowmeter Pulse/Units: 10 gal

RAVEN

30. Press Next.

31. Select the Tank Fill/Level Sensor and enter the Tank Capacity, Current Tank Level, and Low Tank Level for the product.

FIGURE 14. Setup Tank/Bin

Setup Tank/Bin

Product 1 Liquid

Tank Fill/Level Sensor: Tank Level Sensor

Tank Capacity (gal): 1000

Current Tank Level (gal): 1000

Low Tank Level (gal): 50

Alarm?

RAVEN

32. If desired, select the Alarm? checkbox for the Low Tank Level.

33. Press Next.

34. Enter the Preset Rate Values and Rate Bump values for the product.

FIGURE 15. Setup Rates

Setup Rates

Product 1 Liquid ?

	Rate 1	Rate 2	Rate 3
Preset Rate Values (gal/ac)	5.0	7.0	9.0
Rate Bump (gal/ac)	1.0		
Rate Selection	Predefined or Rx		
Display Smoothing	<input checked="" type="checkbox"/>		
Decimal Shift	1		
Standby Pressure (PSI)	0		

RAVEN

35. Select the desired Rate Selection from the drop down.
36. If desired, select the Display Smoothing check box and select the Decimal Shift number.
37. Enter a Standby Pressure.
38. Press Next.
39. If desired, enter a Off Rate Alarm percentage and select the Alarm? check box.

FIGURE 16. Setup Alarms

Setup Alarms

Product 1 Liquid ?

Off Rate Alarm (% off target rate) 20 Alarm?

If Pressure Sensor 1 has a minimum pressure alarm enabled the system will not drop below that pressure to maintain spray pattern.


RAVEN

40. Review the information on the Setup Summary page. If the configuration is not correct, press back and make the necessary adjustments. If the configuration is correct, press Next.

LIQUID RUN PAGE OVERVIEW

The image below is an example of a typical run screen.

FIGURE 17. Liquid Run Screen



PRODUCT TABS

Press on the product tab to select the desired product. This will open the product run screen for that product.

CURRENT PRODUCT RUN SCREEN

The current product run screen displays information for the selected product. Each product run screen will vary based on product configuration.

Data Fields display selected settings and can be changed to the operator's preferences.

FIGURE 18. Liquid Run Screen






TABLE 2. Liquid Run Screen Information

	Button	Description	Function/Operation
	1	Actual Rate	Displays the actual application rate.
	2	Preset Rate Bump	Provides the user the to increase the rate by the preconfigured rates defined during configuration.
	3	Target Rate	Displays the current target rate. The target rate can be adjusted by pressing in the number cell and entering a new number.
	4	Rate Bump/Presets	This will either display Rate Bump or Presents. This increases the rate by the rate bump value defined during configuration.
	5	Flow Rate	Displays the gal/min going through the flow meter.
	6	Traveling Speed	Shows the implement/ machine speed. May be pressed to enter the Self Test Speed Setup menu.
	7	Tank Level	Displays the current tank level.
	8	Section Switch Box Button	Indicates if the switch box is on or off: <ul style="list-style-type: none"> • Green - On • Red - Off Press the switch box button to navigate to a screen that allows the user to turn off the switch boxes for individual sections.
	9	Master Switch Indicator	The Master Switch Indicator shows the status of the master switch. <ul style="list-style-type: none"> • Green - On • Red - Off • Orange - Cycle the master switch
	10	Section Status	Displays the spray status of each section. <ul style="list-style-type: none"> • Green - On • Gray - Off

	Button	Description	Function/Operation
	11	Fence Row	Provides the user the ability to turn the fence rows on or off.
	12	Application Volume	Displays the tally register volume applied.
	13	Applied Acres	Displays the number of acres applied.
	14	Manual/Automatic Toggle	Press this to switch between manual and automatic operation.
	15	Product Tab	Select a tab to view information for that product.
	16	Low Pressure	Low pressure reading.
	17	Quick Start	Select this to quickly configure/start a liquid application.


MAIN

Press main at any time to return to the Current Product Run Screen.

SETUP

Pressing setup opens a screen with many tabs.

FIGURE 19. Setup Tabs



APPLICATOR SETUP TAB

The Applicator Setup Tab provides options to create a new, edit, or remove an applicator. This tab also provides a summary to the section configuration. For more information on the Precision Farming Setup button, refer to Chapter 9, *Precision Farming*.

SYSTEM SETTINGS

The system settings provides many buttons that allow the user to modify the current configuration. The table below describes each button in detail.

TABLE 3. System Settings

Button	Description
Control Valve Setup	The Control Valve button allows the user to adjust the following settings for each product: <ul style="list-style-type: none"> • Valve Response Rate • Control Deadband • Valve Delay • Valve Advance • Control Effort
Rate Sensor Setup	The Rate Sensor Setup button provides the options to adjust the following settings: <ul style="list-style-type: none"> • Flow Meter Calibration • Flow Meter Pulse/Units • Flow Meter Low Limit • Tank Fill Flow Meter Calibration • Tank Fill Flow Meter Pulse/Units There is also the option to perform a catch test and applied product calibration.
Tank Fill Settings	This button allows the user to enter the Tank Capacity, Current Tank Level, and Low Tank Level.
Display Setup Menu	The Display Setup Menu allow the user to configure the main run screen.
Pressure Sensor Setup	This button allows the user to modify the alarm Min and Max for any products that have pressure alarms selected.
Auxiliary Functions	The Auxiliary Functions button allows the user to create new or modify existing auxiliary functions such as RPM sensors.
Scale Setup	Scale Setup allows the user to configure scale options.

ALARM SETTINGS

Press the Alarm Settings tab to modify or update alarm settings such as Off Rate Alarm and the Minimum Flow Rate. There is also an option to update the Pressure Alarm.

RATES SETUP

The Rates Setup tab allows the user to adjust the Preset Rate Values, Rate Bump, Rate Selection, and other values that were entered during the original configuration.

FEATURE UNLOCKS

If there are additional features available for the RCM, enter the provided Activation Key to access these features.

TOTALS

The totals button provides options to access a Current Totals, Device totals, and Distance totals tabs.

DIAGNOSTICS

Selecting the Diagnostics button open a window with tabs for the items listed below.

SYSTEM INFORMATION

Displays information about the RCM including the Hardware Serial Number, Hardware Revision, and Software Version Number.

TESTS

The Tests tab allows the user to select various tests from a dropdown. These list of tests will vary by product configuration.

DIAGNOSTIC TROUBLE CODES

This tab lists Active and Inactive diagnostic trouble codes as well as the ability to Clear the active codes.

SYSTEM SUMMARY

Displays information configured during the setup process but does not provide the option to modify the configuration.


PRODUCT SUMMARY

The Product Summary provides a brief summary for all of the products such as Application Type, Control Valve type, Target Rate, and other settings. This tab does not allow the user to modify the configurations.

AUXILIARY DRIVERS

Auxiliary drivers that were created during configuration are listed in Auxiliary Drivers.

FIGURE 20. Auxiliary Drivers



To give the driver a custom name, press in the Driver Name field and, using the keypad, enter the desired name.

To activate the auxiliary driver, select the driver number button next to the desired driver.

CHAPTER 4

ANHYDROUS AMMONIA (NH₃) OPERATION

NH₃ MACHINE LIST

TABLE 1. RCM NH₃ Machine List

Machine Type	Application Type	Application Mode	Application Mode Uses
• NH ₃ Toolbar	• NA	NH ₃	NH ₃ applicator or single valve configuration.
		NH ₃ HP+	NH ₃ applicator or single valve configuration.

RAVEN ACCUFLOW HP™ PLUS SYSTEMS

OVERVIEW OF OPERATION

The HP+ System utilizes a PWM-controlled hydraulic valve and centrifugal pump to maintain a more consistent system pressure, improving control and increasing standard AccuFlow system capacity. The system is designed to only run the pump when it is needed to achieve target rate.

The pump will control to a target pressure calculated by the controller (RCM). The Standby Pressure is the starting point of the Target Pressure calculation. The Standby Pressure should be set to 5 PSI [35 KPA] above the static pressure of the system (Pressure 1 when no product is being applied and all tank valves are open).

When applying, if the system is not reaching the desired rate, the RCM will increase the Target Pressure it is controlling. It will begin at the Standby Pressure and slowly increase until the rate can be achieved or the PWM has reached its maximum value.

When the machine is stopped the pump will shut off and the Target Pressure will reset to the Standby Pressure

Standby Pressure is entered at the bottom of the Rates Setup page.


NOTE: To ensure proper performance throughout the season, Standby Pressure may need to be adjusted since the static pressure of the system can significantly change as external environmental temperatures increase or decrease.

FIGURE 1. Rates Setup Menu



The RCM Calculated Target Pressure can be viewed at the bottom of the Delivery System page. The Delivery System page can be selected in the System Information dropdown menu.

FIGURE 2. System Information Menu



PUMP FAULT

The pump fault alarm is triggered when the pump PWM output from the RCM is running, and Pressure Sensor 1 (Gauge Tree) is lower or equal to Pressure Sensor 2 (Pump Inlet). Pressure Sensor 1 is on the output side of the pump and Pressure Sensor 2 is on the inlet to the pump so the difference between these 2 sensors is the pressure increase the pump is providing. This alarm is often caused by either a low or empty tank or a restriction on the inlet of the pump. May also be caused if there is not sufficient flow to the hydraulic valve caused by the tractor SCV is being operated backward or the hydraulic hoses have become disconnected, or the PWM valve not operating correctly.

DELTA PRESSURE SENSOR / VAPOR MONITOR

The Delta Pressure Sensor can be used as vapor monitor. Any AccuFlow™ Vortex cooler being controlled by an RCM can be equipped with this sensor. The Sensor can be connected to any unused pressure sensor connection and should be configured as Delta Pressure-NH3 Sensor type. The sensor is temperature transmitter. The RCM will calculate if the pressure and temperature of the NH3 is in the vapor zone or liquid zone of the NH3 pressure/temperature curve. A negative delta pressure reading indicates that the NH3 is in the vapor zone and will not meter properly. Common causes for this are plugged strainers, plugged vapor lines, plugged vapor tube orifice or attempting to apply above the capability of the system.


FIGURE 3. Pressure Sensor Setup Menu



NH3 CONFIGURATION


1. Select the desired Machine Type from the drop down.

FIGURE 4. Name Profile



2. Enter the desired Profile Name.
3. Enter the Application Width.
4. Press Next.
5. Set the appropriate ECU # from the drop-down. This is used to identify, prioritize, and sort RCMs when multiple RCMs are on the same system. For systems with a single RCM, set this to "1".

FIGURE 5. Setup System



6. Enter the desired Number of Products.
7. Press Next.
8. Select the desired Application Mode for each product.


FIGURE 6. Setup Application Type



9. Press Next.

10. Enter the Number of Sections and, if desired, select the Equal Width Sections check box.


FIGURE 7. Setup Sections



11. Press Next.

12. Verify the section widths are correct.

FIGURE 8. Setup Section Width



13. Press Next.

14. If desired, select an Auxiliary Driver. Auxiliary drivers are additional switches that provide a 12V signal to a device.

FIGURE 9. Setup Auxiliary Drivers




NOTE: Unused section drivers are necessary to set up auxiliary drivers and to run independently of any product control.

15. Press Next.


16. Select the Latched Output to allow the driver to stay on until a the driver button is pressed again.

FIGURE 10. Setup Auxiliary Drivers



17. Review the information on the Section Summary screen.

FIGURE 11. Section Summary





18. If the information is correct, press Next. To make adjustments to the configuration, press Back and adjust settings as needed.

19. Select the Product Scale type and the corresponding scale(s).

NOTE: General purpose scales are not associated with a product control channel.

20. Select the desired scale.


FIGURE 12. Scale Setup



21. Press Next.

22. Enter the Min and Max value for the pressure alarms.

FIGURE 13. Setup Pressure Alarms



- 23. Press Next.
- 24. Press Next.
- 25. Enter the Min and Max values for the pressure alarms.
- 26. Select the Control Valve Type.

FIGURE 14. Setup Control Valve



- 27. Enter the desired Valve Response Rate, Control Deadband, and Control Effort.
- 28. Press Next.
- 29. Enter the Flow Meter Calibration.

FIGURE 15. Setup Rate Sensor

Setup Rate Sensor

Product 1 NH3 ?

Flowmeter Calibration

Flowmeter calibration units are (Pulses/10lbs of Actual N) for NH3 applications.

Navigation buttons: [Previous] [Next]

RAVEN

Progress bar

30. Press Next.

31. Enter the Tank Capacity, Current Tank Level, and Low Tank Level values.

FIGURE 16. Setup Tank/Bin

Setup Tank/Bin

Product 1 NH3

Tank Capacity (lb N)

Current Tank Level (N)

Low Tank Level (N) Alarm?

Navigation buttons: [Previous] [Next]

RAVEN

Progress bar

32. If desired, select the Alarm? checkbox for the Low Tank Level.

33. Press Next.


34. Enter the Preset Rate Values and the Rate Bump value.

FIGURE 17. Setup Rates



35. Select the Rate Selection and, if desired, select Display Smoothing.
36. Enter a Standby Pressure. This is the pressure the rate controller will attempt to maintain when all of the sections are off.
37. Press Next.
38. If desired, enter values for the Off Rate Alarm and select the Alarm? checkbox(es) for Off Rate Alarm and the Section Valve Status Feedback Alarm.

FIGURE 18. Setup Alarms



39. Press Next.
40. Review the information on the Setup Summary page.

FIGURE 19. Setup Summary




41. If desired, press Back to adjust the configuration settings. If the configuration is correct, press Next.

NH3 RUN PAGE OVERVIEW

The image below is an example of a typical run screen.

FIGURE 20. NH3 Run Screen



PRODUCT TABS

Press on the product tab to select the desired product. This will open the to product run screen for that product.

CURRENT PRODUCT RUN SCREEN

The current product run screen displays information for the selected product. Each product run screen will vary based on product configuration.

Data Fields display selected settings and can be changed to the operator's preferences.

RUN PAGE OVERVIEW

Data Fields display selected settings and can be changed to the operator's preferences.






TABLE 2. Raven RCM Run Time Widgets

	Button	Description	Function/Operation
	1	Product Tabs	Select a tab to view information for that product.
	2	Applied Area	Displays the number of acres applied.
	3	Application Volume	Displays the tally register volume applied.
	4	Traveling Speed	Displays the current machine traveling speed.
	5	Section Switch Box button	Indicates if the switch box is on or off: <ul style="list-style-type: none"> • Green - On • Red - Off
	6	Actual Rate	Displays the actual application rate.
	7	Target Rate	Displays the target application rate.
	8	Manual/Automatic Toggle	Press this to switch between manual and automatic operation.
	9	Product On/Off Toggle	Press this to manually turn a product on or off.
	11	Preset Rate Button	Provides the user the to increase the rate by the preconfigured rates defined during configuration.
	12	Application Rate	Displays the current application rate in pounds per minute.
	13	Duty Cycle	Displays the current duty cycle.
	14	Master Switch Indicator	The Master Switch Indicator shows the status of the master switch. <ul style="list-style-type: none"> • Green - On • Red - Off • Orange - Cycle the master switch
	15	Implement Sections	Displays if the display section is on or off.
	16	Tank Level Indicator and Fill Button	Displays the current tank fill level.


MAIN

Press main at any time to return to the Current Product Run Screen.

SETUP

Pressing setup opens a screen with many tabs.

FIGURE 21. Setup Tabs



APPLICATOR SETUP TAB

The Applicator Setup Tab provides options to create a new, edit, or remove an applicator. This tab also provides a summary to the section configuration. For more information on the Precision Farming Setup button, refer to Chapter 9, *Precision Farming*.

SYSTEM SETTINGS

The system settings provides many buttons that allow the user to modify the current configuration. The table below describes each button in detail.

TABLE 3. System Settings

Button	Description
Control Valve Setup	The Control Valve button allows the user to adjust the following settings for each product: <ul style="list-style-type: none"> • Valve Response Rate • Control Deadband • Valve Delay • Valve Advance • Control Effort
Rate Sensor Setup	The Rate Sensor Setup button provides the options to adjust the following settings: <ul style="list-style-type: none"> • Flow Meter Calibration • Flow Meter Pulse/Units • Flow Meter Low Limit • Tank Fill Flow Meter Calibration • Tank Fill Flow Meter Pulse/Units There is also the option to perform a catch test and applied product calibration.
Tank Fill Settings	This button allows the user to enter the Tank Capacity, Current Tank Level, and Low Tank Level.
Display Setup Menu	The Display Setup Menu allows the operator to configure the main run screen.
Pressure Sensor Setup	This button allows the user to modify the alarm Min and Max for any products that have pressure alarms selected.
Auxiliary Functions	The Auxiliary Functions button allows the user to create new or modify existing auxiliary functions.
Scale Setup	Scale Setup allows the user to configure scale options.

ALARM SETTINGS

Press the Alarm Settings tab to modify or update alarm settings such as Off Rate Alarm and the Minimum Flow Rate. There is also an option to update the Pressure Alarm.

RATES SETUP

The Rates Setup tab allows the user to adjust the Preset Rate Values, Rate Bump, Rate Selection, and other values that were entered during the original configuration.

FEATURE UNLOCKS

If there are additional features available for the RCM, enter the provided Activation Key to access these features.

TOTALS

The totals button provides options to access a Current Totals, Device totals, and Distance totals tabs.

DIAGNOSTICS

Selecting the Diagnostics button opens a window with tabs for the items listed below.

SYSTEM INFORMATION

Displays information about the RCM including the Hardware Serial Number, Hardware Revision, and Software Version Number.

TESTS

The Tests tab allows the user to select various tests from a dropdown. These list of tests will vary by product configuration.

DIAGNOSTIC TROUBLE CODES

This tab lists Active and Inactive diagnostic trouble codes as well as the ability to Clear the active codes.

SYSTEM SUMMARY

Displays information configured during the setup process but does not provide the option to modify the configuration.


PRODUCT SUMMARY

The Product Summary provides a brief summary for all of the products such as Application Type, Control Valve type, Target Rate, and other settings. This tab does not allow the user to modify the configurations.

AUXILIARY DRIVERS

Auxiliary drivers that were created during configuration are listed in Auxiliary Drivers.

FIGURE 22. Auxiliary Drivers



To give the driver a custom name, press in the Driver Name field and, using the keypad, enter the desired name.

To activate the auxiliary driver, select the driver number button next to the desired driver.

CHAPTER

SPREADER OPERATION

5

SPREADER MACHINE LIST

TABLE 1. RCM Spreader Machine List

Machine Type	Application Type	Application Mode	Application Mode Uses
<ul style="list-style-type: none"> • Self-Propelled Spreader • Pull-Behind Spreader 	<ul style="list-style-type: none"> • Granular Fertilizer • Granular Seed 	Dry Manure/Litter	Granular full width using product scales to adjust product density on the go during in-field operations.
		Granular Full Width	Dry or seed application using a single shutoff section. Application rate is entered and documented as lbs/acre [kg/ha].
		Granular RPM Compensated	Dry or seed application using multiple shutoff sections. Meter/conveyor RPM is controlled/compensated based upon machine speed and active width as sections turn on and off. Application rate is entered and documented as lbs/acre [kg/ha].
		Granular RPM Maintained	Granular multi-section RPM maintained dry or seed application using multiple shutoff sections. Meter/conveyor RPM is controlled/compensated based upon machine speed. Meter/conveyor RPM is not compensated for changes in active width as sections turn on and off. Meter/conveyor will be stopped when all sections are off. Application rate is entered and documented as lbs/acre [kg/ha].

TABLE 1. RCM Spreader Machine List

Machine Type	Application Type	Application Mode	Application Mode Uses
(Cont.) • Self-Propelled Spreader • Pull-Behind Spreader	(Cont.) • Granular Fertilizer • Granular Seed	Granular Split Belt	Dry or seed application using one control valve of a split meter/conveyor RPM is available for each section. Meter/Conveyor RPM is not compensated for changes in active width as left or right sections turn on and off. Meter/conveyor will be stopped when both sections are off.
		Granular Dual Control Valve	Dual Control Valve Dry or seed application using dual PWM control valves to independently control a left and right meter/conveyor section. Encoder feedback of meter or conveyor RPM is available for each section. Meter/conveyor RPM is independently controlled/compensated based on machine speed. Sections are turned off by closing the PWM control valve.

Spreader configuration on the RCM can also support the following legacy applications:

TABLE 2. Legacy Granular Modes

Legacy Granular Application Mode	New Application Mode	Mode Details
Gran 1	Granular Full Width Selection	Dry or seed application using a single shutoff section. Application rate is entered and documented as Pounds/Acre (Kilograms/Hectare).
Gran 2	Granular Section Control RPM Maintained	Dry or seed application using multiple shutoff sections. Meter/conveyor RPM is controlled/compensated based upon machine speed and active width as sections turn on and off. Application rate is entered and documented as lbs/acre [kg/ha].
Gran 3	Granular Split Tank/ Dual Encoder	Dry or seed application using one control valve for a split meter/conveyor with shutoff control of two independent sections. Encoder feedback of meter or conveyor RPM is available for each section. Meter/conveyor RPM is controlled/compensated based upon the vehicle speed. Meter/conveyor RPM is not compensated for changes in active section width as left or right sections turn on and off. Meter/conveyor will be stopped when both sections are off.
Gran 4	Granular Section Control RPM Maintained	The Granular Section Control RPM Maintained is listed above for Gran 2. If this is the correct mode for the Legacy Gran 4, we should be able to copy the mode details from above.

TABLE 2. Legacy Granular Modes

Legacy Granular Application Mode	New Application Mode	Mode Details
Gran 5	Granular Section Control RPM Compensated	<p>Dry or seed application using multiple shutoff sections. Meter/conveyor RPM is controlled/compensated based upon vehicle speed. Meter/conveyor RPM is not compensated for changes in active width as sections turn on and off. Meter/conveyor will be stopped when all sections are off. Application rate is entered and documented as lbs/acre [kg/ha].</p>
None	Dual Control Valve	<p>Dry or seed application using dual PWM control valves to independently control a left and right meter/conveyor section.</p> <p>Encoder feedback of meter or conveyor RPM is available for each section. Meter/conveyor RPM is independently controlled/compensated based upon vehicle speed. Sections are turned off by closing the PWM control valve.</p>
None	Granular Meter Per Section	<p>Dry or seed application using PWM control valves to independently control a meter/conveyor section.</p> <p>Up to 16 individual control sections can be configured. Encoder feedback of meter or conveyor RPM is available for each section. Meter/conveyor RPM is independently controlled/compensated based upon vehicle speed. Sections are turned off by closing the PWM control valve.</p> <p>NOTE: This mode is only available when the Generic machine type selected or in Air Cart mode.</p>

SPREADER CONFIGURATION

1. Use the **Machine Type** drop down to select the *Self-Propelled Spreader* option.

FIGURE 1. Name Profile Page


2. Enter the desired **Profile Name**.
3. Enter the Application Width of the implement.
4. Touch the **Next** button.
5. Set the appropriate ECU # from the drop-down. This is used to identify, prioritize, and sort RCMs when multiple RCMs are on the same system. For systems with a single RCM, set this to "1".

FIGURE 2. Setup System Page

6. Enter the desired Number of Products.

7. Touch the **Next** button.
8. Use the drop-down option to select the desired number of spinner/fans.

FIGURE 3. Setup Fan/Spinner RPM Page



9. If desired, select the **Enable Fan/Spinner RPM Control** check box for automatic control of fan or spinner speed.
10. Touch the **Next** button.
11. Use the drop-down options for each configured product to select the **Application Type** for each control channel.

NOTE: The last product control channel will always show as RPM Spinner/Fan. This channel is not configurable.

NOTE: The last product control channel will always show as RPM Spinner/Fan. This channel is not configurable.

FIGURE 4. Setup Application Type Page



12. Touch the **Next** button.

13. Use the drop-down options to select the **Application Mode** for each product control channel.


FIGURE 5. Setup Application Type Page Two



14. Touch the **Next** button.

15. If the machine offers Aux-N inputs on the joystick or command arm to allow RCM functions to be assigned to the buttons.

FIGURE 6. Aux-N Page



16. Touch the **Next** button.

17. Review and confirm the section driver configuration details on the Setup Section Groups page. Toggle the drop-down option to **Yes** or **No** for the on-screen display which matches the actual driver configuration.

FIGURE 7. Setup Section Groups Page




18. Touch the **Next** button.

FIGURE 8. Enter the **Number of Sections**.Setup Selections Page



19. If desired, enable the **Equal Width Sections** check box.
20. Enable the **Granular Product Sections Power to Apply** if section switches provide 12 V power to turn on the section. If this option is disabled, switches will remove 12 V power to turn on sections.
21. Touch the **Next** button.
22. Verify the entered section widths and units are correct.


FIGURE 9. Setup Section Width Page



23. Touch the **Next** button.

24. If desired, use the drop-down options to select an **Auxiliary Driver**. Auxiliary drivers are additional switches that provide a 12V signal to a device.

FIGURE 10. Setup Auxiliary Drivers Page




NOTE: Unused section drivers are necessary to set up auxiliary drivers and to run independently of any product control.

25. Touch the **Next** button.

26. Enable the **Latched Output** option to allow the auxiliary driver to stay on until the driver button is pressed again.


FIGURE 11. Setup Auxiliary Drivers Page



27. Touch the **Next** button.


28. Review the section configuration details on the **Section Summary** screen.

FIGURE 12. Section Summary Page



29. If the information is correct, touch the **Next** button. To make adjustments to the configuration, touch the **Back** button and adjust settings as needed.
30. Use the drop-down option to select the type of scale used and assign the corresponding product scale(s).


FIGURE 13. Scale Setup Page



31. Touch the **Next** button.

32. Enable any applicable auxiliary functions.

FIGURE 14. Setup Auxiliary Functions Page




33. Touch the **Next** button.

34. Enter the fan or spinner speed calibration value as the RPM Calibration.

35. Enter the **RPM Low Limit**, and **RPM High Limit** values to set the minimum and maximum fan or spinner speeds.

36. If desired, enable the **Alarm** check box to enable an on-screen prompt if the RPM exceeds the set limits.


FIGURE 15. Setup Fan/Spinner RPM Calibration Page



37. Touch the **Next** button.

38. Assign the product channels to the configured RPM sensor. Select the check box(es) for the control channels that will be assigned to each RPM Sensor.

FIGURE 16. Setup RPM Sensor Assignment Page



39. Select the Control Valve Type for the product.

FIGURE 17. Setup Control Valve Page



The screenshot shows a control panel titled "Setup Control Valve" for "Product 1 Granular". It features a dropdown menu for "Control Valve Type", three input fields for "Valve Response Rate (1-100)", "Control Deadband (%)", and "Enable PWM Smart Control" (a checkbox). At the bottom, there are navigation buttons: a left arrow, a "RAVEN" label, and a right arrow.

40. Enter the Valve Response Rate.

41. Enter the Control Deadband.

42. If desired, select Enable PWM Smart Control.

43. Touch the **Next** button.

FIGURE 18. Enter the Coil Frequency, PWM High Limit, PWM Low Limit, and PWM Startup for the product. Setup PWM Page



The screenshot shows a control panel titled "Setup PWM" for "Product 1 Granular". It features four input fields for "Coil Frequency (Hz)", "PWM High Limit (%)", "PWM Low Limit (%)", and "PWM Startup (%)". At the bottom, there are navigation buttons: a left arrow, a "RAVEN" label, and a right arrow.

44. Touch the **Next** button.


FIGURE 19. Enter the Product Density, Spreader Constant, Pulses/Revolution, and Gate Height. The Gate Height must be between one and three inches. Setup Rate Sensor Page



45. Touch the **Next** button.

46. Enter the Tank Capacity and Low Tank Level.

FIGURE 20. Setup Tank/Bin Page



47. Enter a non-zero value for the Tank Capacity and Low Tank Level values, if desired.

48. If a non-zero value is entered for the Current Tank Level and Low Tank Level, enable the Alarm option to enable an audible alarm when the product level in the tank reaches the set low tank level during field operation.

49. Enable the Low Bin Level Sensor if an ultrasonic bin level sensor is equipped for monitoring the product remaining in the bin.

50. Select the Mid Bin Level Sensor Type.

NOTE: To test the sensor type, place an object in front of the sensor. If the voltage reads 12 V it is a PNP sensor. If it reads ground, it is a NPN sensor.

51. Touch the **Next** button.

52. Enter the Preset Rate Values and the Rate Bump value.

FIGURE 21. Setup Rates Page

The screenshot shows the 'Setup Rates' interface for 'Product 1 Granular'. It features a table for 'Preset Rate Values (lb/ac)' with columns for 'Rate 1', 'Rate 2', and 'Rate 3'. Below this is a 'Rate Bump (lb/ac)' field, a 'Rate Selection' dropdown menu, a 'Display Smoothing' checkbox, and a 'Decimal Shift' dropdown menu. At the bottom, there are 'Previous' and 'Next' navigation buttons, a 'RAVEN' logo, and a progress bar.

53. Select the Rate Selection and Decimal Shift values.

54. If desired, enable Display Smoothing to allow the system to smooth the rate display during field operation. With this feature enabled, the system will display the target rate as long as the actual rate is within 10% of the actual application rate.

55. Touch the **Next** button.

56. If desired, enter values for the Off Rate Alarm and Split Belt/Dual Encoder Alarm and select the Alarm? checkbox(es) to enable audible alarms for the configured conditions.

FIGURE 22. Setup Alarms Page



57. Touch the **Next** button.

58. Repeat steps step 39 through step 56 for all products.

59. Review the information on the Setup Summary page.

FIGURE 23. Setup Summary Page



60. If desired, press Back to adjust the configuration settings. If the configuration is correct, press Next.

MANURE/LITTER CONFIGURATION

When paired with a scale system, the Raven Rate Control Module (RCM) can be used to compensate for varying product density within a spreader load. This capability offers optimal consistency of application even when the product composition is highly variable.

The dynamic calibration feature continually adjusts the “Density Factory” based upon user-entered settings for:

- Adjustment Frequency - amount of product dispensed between adjustments
- Adjustment Sensitivity - percent of adjustment that should be made based upon the sample

In addition, the clean out feature dynamically adjusts the spreader constant for the final port of a load based upon a user-entered trigger weight. This feature increases the PWM duty cycle to a maximum over time to better maintain an even distribution pattern as the load trails off while maintaining the calibration settings for applying a normal load.

A Level 3 RCM is required for these features and is only available for the Litter/Manure application mode configured for a granular spreader equipped with a product scale. Applicable part numbers include:


TABLE 3. Litter/Manure Part Numbers

Part Number	Description
063-0173-953	Raven Rate Control Module Level 3
117-7100-007	Kit - RCM LVL 3 Gen 1 ISOBUS ECU Harness
117-7100-008	Kit - RCM LVL 3 Gen 3 ECU Harness

DYNAMIC CALIBRATION

To access settings for Dynamic Calibration, navigate to the Rate Sensor Setup Page:

FIGURE 24. Setup Rate Sensor Page




1. On the Setup Rate Sensor screen, set the Density Factor to 70 lb/ft³ [1,121 kg/m³] as a starting point.

NOTE: The other settings on the Setup Rate Sensor screen are specific to the spreader equipment.

2. Select the "Dynamic Cal Setup" button.
3. Set the Adjustment Frequency and Adjustment Sensitivity settings to adjust the Density Factor to the correct apron speed needed to apply at the desired rate.

FIGURE 25. Dynamic Cal Setup Page



DENSITY ADJUSTMENT FREQUENCY

The Adjustment Frequency value is used to determine how often the controller recalculates the Density Factor. Enter the weight in pounds [kilograms] dispensed before the controller makes an adjustment. The recommended starting point is 1/20th of the total load weight. This will result in 20 density adjustments per load. On very uneven loads, the Adjustment Frequency weight value can be decreased, however, rate fluctuation may be observed. If excessive rate fluctuation is occurring, increase the value.

ADJUSTMENT SENSITIVITY


The Adjustment Sensitivity percentage is used to set how aggressively the controller will adjust the Density Factor. It is recommended to leave this setting at the default setting of 50% unless otherwise instructed.

If the total applied weight displayed on the controller is not matching the actual scale weight applied, the Sensitivity percentage may be increased (not to exceed 75%). If erratic rates are observed, reduce this value (not to be set below 25%) but may lead to some variation between controller totals and scale totals.

CLEAN OUT SETUP

1. On the Setup Rate Sensor screen, press the "Clean Out Setup" button to access the Clean Out settings.


FIGURE 26. Setup Rate Sensor Page



CLEAN OUT MODE

The Clean Out Mode is used to compensate for the end of a load when the beaters or spinners are no longer full. The apron chain will continue to speed up until it is at full speed. The controller will resume normal operation when the spreader has been refilled to above the trigger weight. Configuration of the clean out mode consists of two settings - Trigger Weight and Clean Out Duration.

FIGURE 27. Cleanout Setup Page



TRIGGER WEIGHT

When the scale reaches the weight set in the Trigger Weight field, the clean out mode will start. Set the Trigger Weight to the scale reading when the opening to the beaters or spinners is no longer completely covered.

CLEAN OUT DURATION

Enter the time in seconds during which the controller will gradually increase the apron chain speed. A value between 15 and 25 is a recommended starting point for the Clean Out Duration setting.


The steeper the angle of the material left in the spreader when the Trigger Weight is reached, the shorter the Duration value should be.

LITTER/MANURE OPERATION TIPS

For greatest accuracy and optimal performance:


- Use Quick Start feature to prime the Spreader. Toggle the master switch ON and press the Quick Start button in the lower, right corner of the RCM run screen. The Quick Start feature will start the apron to run for up to 15 seconds while the equipment remains stopped. Toggle the master switch OFF to stop if necessary. Allow the apron to run until material starts to come out. Completing the Quick Start process will fill up the dead area between the gate and the beaters and help ensure that material is applied when the system is enabled for in-field application.

FIGURE 28. Quick Start Feature



- Full loads will have better accuracy than partial loads. The controller will still adjust for a partial load, but the changes in Density factor will be much greater.
- The Density Factor may be monitored by adding a widget to the main run screen. While the widget is not required to operate, it is helpful for monitoring the system. The Density Factor will increase as the beaters are more full or the material is heavier.


FIGURE 29. Product Density



SPREADER RUN PAGE OVERVIEW

The image below is an example of a typical run screen.

FIGURE 30. Spreader Run Page



PRODUCT TABS

Touch the product tab to select the desired product. This will open the to product run screen for that product.

CURRENT PRODUCT RUN SCREEN

The current product run screen displays information for the selected product. Each product run screen will vary based on product configuration.

Data Fields display selected settings and can be changed to the operator's preferences.

RUN PAGE OVERVIEW

Data Fields display selected settings and can be changed to the operator's preferences.

FIGURE 31. Run Screen






TABLE 4. Raven RCM Run Time Widgets

	Button	Description	Function/Operation
	1	Product Tabs	Select a tab to view information for that product.
	2	Applied Area	Displays the number of acres applied.
	3	Total Volume Applied	Displays the total volume of product applied since the last time the tally was reset.
	4	Traveling Speed	Displays the current machine traveling speed.
	5	Section Switchbox Button	Indicates if the switchbox is on or off: <ul style="list-style-type: none"> • Green - On • Red - Off
	6	Actual Rate	Displays the actual application rate.
	7	Target Rate	Displays the target application rate.
	8	Manual/Automatic Toggle	Press this to switch between manual and automatic operation.
	9	Product On/Off Toggle	Press this to manually turn a product on or off.
	11	Preset Rate Button	Provides the user the to increase the rate by the preconfigured rates defined during configuration.
	12	Application Rate	Displays the current application rate in pounds per minute.
	13	Duty Cycle	Displays the current duty cycle.
	14	Master Switch Indicator	The Master Switch Indicator shows the status of the master switch. <ul style="list-style-type: none"> • Green - On • Red - Off • Orange - Cycle the master switch
	15	Implement Sections	Displays if the display section is on or off.
	16	Tank Level Indicator and Fill Button	Displays the current tank fill level.
Spinners			
Cycle Master			

	Button	Description	Function/Operation
Quick Start			


MAIN

Press main at any time to return to the Current Product Run Screen.

SETUP

Pressing setup opens a screen with many tabs.

FIGURE 32. Setup Tabs



APPLICATOR SETUP TAB

The Applicator Setup Tab provides options to create a new, edit, or remove an applicator. This tab also provides a summary to the section configuration. For more information on the Precision Farming Setup button, refer to Chapter 9, *Precision Farming*.

SYSTEM SETTINGS

The system settings provides many buttons that allow the user to modify the current configuration. The table below describes each button in detail.

FIGURE 33.




TABLE 5. System Settings

Button	Description
Control Valve Setup	The Control Valve button allows the user to adjust the following settings for each product: <ul style="list-style-type: none"> • Valve Response Rate • Control Deadband • Valve Delay • Valve Advance • Control Effort
Rate Sensor Setup	Allows the operator to modify/edit the calibration value for the flow meter or encoder used on the control channel.
Tank Fill Settings	This button allows the user to enter the Tank Capacity, Current Tank Level, and Low Tank Level.
Display Setup Menu	The Display Setup Menu allows the user to configure the main run screen.
Pressure Sensor Setup	This button allows the user to modify the alarm Min and Max for any products that have pressure alarms selected.
Auxiliary Functions	The Auxiliary Functions button allows the user to create new or modify existing auxiliary functions.
Actuator Position Setup	The Setup menu allows entry of flow rate for each actuator position

ALARM SETTINGS

Press the Alarm Settings tab to modify or update alarm settings such as Off Rate Alarm and the Minimum Flow Rate. There is also an option to update the Pressure Alarm.

RATES SETUP

The Rates Setup tab allows the user to adjust the Preset Rate Values, Rate Bump, Rate Selection, and other values that were entered during the original configuration.

FEATURE UNLOCKS

If there are additional features available for the RCM, enter the provided Activation Key to access these features.

TOTALS

The totals button provides options to access a Current Totals, Device totals, and Distance totals tabs.

DIAGNOSTICS

Selecting the Diagnostics button opens a window with tabs for the items listed below.

MANURE/LITTER SPREADER CONFIGURATION AND SETTINGS


An RCM with level 3 unlocks can apply manure/litter. This is possible by adjusting the density factor in the Dynamic Cal Setup and Clean Out Setup settings during the initial implement configuration.

FIGURE 34. Manure/Litter Configuration

CLEAN OUT SETUP

Clean out mode is used to compensate for the end of a load when the beaters/spinners are no longer full. The apron chain will continue to speed up until the chain is at full speed. After refilling above the trigger weight, the controller will resume normal operation.

FIGURE 35. Cleanout Setup



TRIGGER WEIGHT

Cleanout mode will start when the Trigger Weight is met. Set this by watching the end of the load and monitoring the scale reading when the opening to the beaters/spinners are no longer completely covered.

CLEANOUT DURATION

Cleanout duration sets the amount of time the controller uses to increase the apron chain speed. The steeper the angle of material left in the spreader when the trigger weight is hit, the smaller the duration. Generally a value of 15 to 25 is a good starting point.

DYNAMIC CALIBRATION

Dynamic calibration adjusts the density factor used to determine the desired apron speed.

FIGURE 36. Dynamic Calibration

Dynamic Cal Setup

PR1

Enable Dynamic Cal

Density Adjustment Frequency (lb)

Adjustment Sensitivity (%)

RAVEN

ADJUSTMENT FREQUENCY

Adjustment Frequency determines how often the controller recalculates the density factor in lb [kg]. The recommended starting point is 1/20 of the total load weight. This will result in 20 density adjustments per load. On uneven loads this number may fluctuate. If excessive fluctuation is observed, increase the adjustment frequency number.

ADJUSTMENT SENSITIVITY

Adjust Sensitivity sets how aggressively the controller will change the density factor. A good starting point for this setting is 50% and, unless otherwise instructed, should remain at this number. Increase the sensitivity if the controller's total applied weight is not matching the applied scale weight but do not exceed 75%. Lower the number if erratic rates occur but not below 25%.

CHAPTER

AIR CART OPERATION

6

MACHINE TYPES

This section applies to air carts utilizing the following configuration:

TABLE 1. RCM Machine List

Machine Type	Application Type	Application Mode	Application Mode Uses
<ul style="list-style-type: none"> • Air Cart • Generic 	<ul style="list-style-type: none"> • Liquid • Granular 	Liquid	Standard liquid system.
		Granular Full Width	Dry or seed application using a single shutoff section. Application rate is entered and documented as lbs/acre [kg/ha].
		Granular RPM Compensated	Dry or seed application using multiple shutoff sections. Meter/conveyor RPM is controlled/compensated based upon machine speed and active width as sections turn on and off. Application rate is entered and documented as lbs/acre [kg/ha].
		Granular RPM Maintained	Granular multi-section RPM maintained dry or seed application using multiple shutoff sections. Meter/conveyor RPM is controlled/compensated based upon machine speed. Meter/conveyor RPM is not compensated for changes in active width as sections turn on and off. Meter/conveyor will be stopped when all sections are off. Application rate is entered and documented as lbs/acre [kg/ha].
		Granular Split Belt	Dry or seed application using one control valve of a split meter/conveyor RPM is available for each section. Meter/Conveyor RPM is not compensated for changes in active width as left or right sections turn on and off. Meter/conveyor will be stopped when both sections are off.

TABLE 1. RCM Machine List

Machine Type	Application Type	Application Mode	Application Mode Uses
(Cont.) • Air Cart • Generic	(Cont.) • Liquid • Granular	Granular Dual Control Valve	Dual Control Valve Dry or seed application using dual PWM control valves to independently control a left and right meter/conveyor section. Encoder feedback of meter or conveyor RPM is available for each section. Meter/conveyor RPM is independently controlled/compensated based on machine speed. Sections are turned off by closing the PWM control valve.
		Granular Meter Per Section	Dry or seed application using PWM control valves to independently control a meter/conveyor section. Up to 16 individual control sections can be configured. Encoder feedback of meter or conveyor RPM is available for each section. Meter/conveyor RPM is independently controlled/compensated based on machine speed. Sections are turned off by closing the PWM control valve.

Air cart configuration on the RCM can also support the following legacy applications:

TABLE 2. Legacy Granular Modes

Legacy Granular Application Mode	New Application Mode	Mode Details
Gran 1	Granular Full Width Selection	Dry or seed application using a single shutoff section. Application rate is entered and documented as Pounds/Acre (Kilograms/Hectare).
Gran 2	Granular Section Control RPM Maintained	Application Mode - Granular Multi-Section RPM Maintained dry or seed application using multiple shutoff sections. Meter/conveyor RPM is controlled/compensated based on machine speed. Meter/conveyor RPM is not compensated for changes in active width as section turn on and off. Meter/conveyor will be stopped when all sections are off. Application rate is entered and documented as Pounds/Acre (Kilograms/Hectare).
Gran 3	Granular Split Tank/ Dual Encoder	Dry or seed application using one control valve of a split meter/conveyor RPM is available for each section. Meter/Conveyor RPM is not compensated for changes in active width as left or right sections turn on and off. Meter/conveyor will be stopped when both sections are off.

Legacy Granular Application Mode	New Application Mode	Mode Details
Gran 4	Granular Section Control RPM Maintained	Application Mode - Granular Multi-Section RPM Maintained dry or seed application using multiple shutoff sections. Meter/conveyor RPM is controlled/compensated based on machine speed. Meter/conveyor RPM is not compensated for changes in active width as section turn on and off. Meter/conveyor will be stopped when all sections are off. Application rate is entered and documented as Pounds/Acre (Kilograms/Hectare).
Gran 5	Granular Section Control RPM Compensated	Dry or seed application using multiple shutoff sections. Meter/conveyor RPM is controlled/compensated based on machine speed and active width as sections turn on and off. Application rate is entered and documented as Pounds/Acre (Kilograms/Hectare).
None	Dual Control Valve	Dual Control Valve Dry or seed application using dual PWM control valves to independently control a left and right meter/conveyor section. Encoder feedback of meter or conveyor RPM is available for each section. Meter/conveyor ROM is independently controlled/compensated based on machine speed. Sections are turned off by closing the PWM control valve.
None	Granular Meter Per Section	Dry or seed application using PWM control valves to independently control a meter/conveyor section. Up to 16 individual control sections can be configured. Encoder feedback of meter or conveyor RPM is available for each section. Meter/conveyor RPM is independently controlled/compensated based on machine speed. Sections are turned off by closing the PWM control valve.

AIR CART CONFIGURATION

This configuration is an sample air cart configuration. Each configuration will vary so some of the steps shown below may not apply to your configuration or some steps may need to be repeated multiple times.

1. Enter a Profile Name.

FIGURE 1. Name Profile

2. Select Air Cart as the Machine Type.
3. Enter the Application Width and select the desired unit of measure. The application width is typically the boom width.
4. Press Next.
5. Set the appropriate ECU # from the drop-down. This is used to identify, prioritize, and sort RCMs when multiple RCMs are on the same system. For systems with a single RCM, set this to "1".

FIGURE 2. Setup System

ECU S/N	ECU #	Number of Products
RCM-1039		

6. Enter the total desired Number of Products.
7. Press Next.
8. Use the Number of Products drop down to select the number of spinners or fans that are monitored or controlled by the ECU from the drop down.

FIGURE 3. Setup Fan/Spinner RPM



9. If desired, select the Enable Fan/Spinner RPM Control check box. This will allow the spinner/fan to be controlled from the main RCM run screen.
10. Press Next.
11. Select the desired application type for each product.

FIGURE 4. Setup Application Type



12. Press Next.

- Use the Application Mode drop down to select the correct control type for the product. Review Table 1, "RCM Machine List," on page 77 for details on available control types.

FIGURE 5. Setup Application Type




- Press Next.
- Select Yes or No from the Setup Section Groups screen. Setting up section groups shares the product drivers in the harness between all products.

FIGURE 6. Setup Section Groups



- Press Next.
- Enter the Number of Sections. This is the number of sections as defined by the harness configuration.

FIGURE 7. Setup Sections



18. If desired, select Equal Width Sections. This will evenly divide the machine width into equal sections.
19. If desired, select Master Clutch. This applies if there is a master clutch on the air cart that will control a magnetic clutch to engage or disengage the drive.
20. If applicable, select the Granular Product Sections Power to Apply checkbox. Select this if the controller will provide power on the section signal wire when the section is on. Leave unchecked if the controller will provide power to the section signal wire when the section is off.
21. Press Next.
22. Select the Starting Section Number for Section Group 1. A section group is a set of sections that will apply the same product at the same rate.

FIGURE 8. Setup Section Harnessing



23. Enter the Number of Sections for the first section group.
24. If desired, select Equal Section Widths.


25. If applicable, enter the Starting Section Number for Section Group 2. In this case, it is five because it must be the first section not being used by the previous section group.
26. Press Next.
27. Select the Section Groups for each Product.

FIGURE 9. Setup Section Group Assignment




28. Select Next.
29. Review the widths for each section. If needed, select the measurement box next to section and enter a different width.

FIGURE 10. Setup Section Width



30. Press Next.
31. If desired, select a function for the Auxiliary Drivers. Auxiliary drivers are additional switches that provide a 12V signal to a device.


FIGURE 11. Setup Auxiliary Drivers



32. Press Next.

33. If desired, select latched for the auxiliary output. Latched means that, once selected, the signal remains constant until the button is pressed again. Leaving the check box unselected means that the signal is only active when the button is being pressed.

FIGURE 12. Auxiliary Drivers Assignments



34. Press Next.

35. Review the Section Summary.

FIGURE 13. Section Summary




36. Press Next.

37. Enter the blockage sensor information for each section. The Starting Sensor number must be the next number after the previous section. In the case below, since section five has twelve sensors, the Starting Sensor number for Section 6 would be 13.

NOTE: Blockage sensor setup is only required when configuring an RBM system.


FIGURE 14. Setup Blockage Sensors



38. Press Next.

39. Select the desired scale type from the Scale Setup drop down.

FIGURE 15. Scale Setup




40. If desired, select the Product Scale check box. This assigns the scale to a product.

41. Press Next.

42. Select the desired product(s) that will have a Pressure Sensor.


FIGURE 16. Setup Pressure Assignment



43. Press Next.

44. Enter the Min and Max pressures for each pressure setting.

FIGURE 17. Setup Pressure Alarms



45. if desired, select the Alarm? check box to activate alarms.

46. Press Next.

47. Assign the RPM Sensor for each of the products.

FIGURE 18. Setup RPM Sensor Assignment



48. Press Next.

49. Select the Control Valve Type for the first product.

FIGURE 19. Setup Control Valve

Setup Control Valve

Product 1 Liquid ?

Control Valve Type Standard

Valve Response Rate (1-100) 50

Control Deadband (%) 3

Valve Delay (seconds) 0.0

Valve Advance (seconds) 0.0

Control Effort (%) 35

RAVEN

50. Enter the Valve Response Rate.
51. Enter the Control Deadband percentage.
52. Enter the Valve Delay value.
53. Enter the Valve Advance time.
54. Enter the Control Effort percentage.
55. Press Next.
56. Enter the Flow Meter Calibration number.

FIGURE 20. Setup Rate Sensor

Setup Rate Sensor

Product 1 Liquid ?

Flowmeter Calibration 1440

Flowmeter Pulse/Units 10 gal

RAVEN

57. Select the Flow Meter Pulse/Units.
58. Press Next.
59. Enter the Preset Rate Values for each rate.

FIGURE 21. Setup Rates

Setup Rates

Product 1 Liquid ?

	Rate 1	Rate 2	Rate 3
Preset Rate Values (gal/ac)	10.0	15.0	20.0

Rate Bump (gal/ac): 1.0

Rate Selection: Predefined or Rx

Display Smoothing:

Decimal Shift: 1

Navigation: [Back] RAVEN [Next]

60. Enter the desired Rate Bump increment.
61. Select the Rate Selection.
62. Enable Display Smoothing if desired.
63. Select the Decimal Shift quantity.
64. Press Next.
65. Enter the desired Off Rate Alarm percentage.

FIGURE 22. Setup Alarms

Setup Alarms

Product 1 Liquid ?

Off Rate Alarm (% off target rate): 20

Alarm?

Enter minimum flow rate required to maintain spray pattern.

Minimum Flow Rate: 10.0 (gal/min)

Navigation: [Back] RAVEN [Next]

66. Enter the Minimum Flow Rate.
67. Press Next.
68. Review the Setup Summary. If necessary, press Back to adjust the settings.

FIGURE 23. Setup Summary




69. Press Next.

AIR CART RUN PAGE OVERVIEW

The image below is an example of a typical run screen.

FIGURE 24. RCM Main Screen



PRODUCT TABS

Press on the product tab to select the desired product. This will open the to product run screen for that product.

CURRENT PRODUCT RUN SCREEN

The current product run screen displays information for the selected product. Each product run screen will vary based on product configuration.

Data Fields display selected settings and can be changed to the operator's preferences.

FIGURE 25. Air Cart Run Screen





TABLE 3. Air Cart Run Screen Information

	Button	Description	Function/Operation
	1	Volume Per Minute	Indicates the application rate per minute.
	2	Area Per Hour	Indicates the how many acres per hour are being applied.
	3	PWM Readout	Shows the operating percentage of the PWM valve.
	4	Traveling Speed	Shows the implement/machine speed.
	5	Section Switch Box Button	Indicates if the switch box is on or off: <ul style="list-style-type: none"> • Green - On • Red - Off
	6	Actual Rate	Displays the actual application rate.

	Button	Description	Function/Operation
	7	Target Rate	Displays the current target rate. The target rate can be adjusted by pressing in the number cell and entering a new number.
	8	Manual/Automatic Toggle	Press this to switch between manual and automatic operation.
	9	Product On/Off Toggle	Press this to manually turn a product on or off.
	10	Predefined Rate 1 Button	Select this button to start applying at the rate listed on the button. Refer to "Rates Setup" on page 95 for more information on adjusting rates.
	11	Predefined Rate 2 Button	Select this button to start applying at the rate listed on the button. Refer to "Rates Setup" on page 95 for more information on adjusting rates.
	12	Predefined Rate 3 Button	Select this button to start applying at the rate listed on the button. Refer to "Rates Setup" on page 95 for more information on adjusting rates.
	13	Product Tab	Select a tab to view information for that product.
	14	Quick Start Button	Press the quick start button to quickly configure a product.
	15	Master Switch Indicator	The Master Switch Indicator shows the status of the master switch. <ul style="list-style-type: none"> • Green - On • Red - Off • Orange - Cycle the master switch
	16	Tank Level Indicator and Fill Button	Indicated the fill level of the tank.
	17	Implement Sections	Displays the section number. The section status will display below the implement section. <ul style="list-style-type: none"> • Red - Off • Green - On • Blue - Liquid
	18	Fan Speed	Indicates the fan speed in RPM.
	19	Meter/Shaft RPM	Indicates the shaft or meter RPM as read by an encoder.


MAIN

Press main at any time to return to the Current Product Run Screen.

SETUP

Pressing setup opens a screen with many tabs.

FIGURE 26. Setup Tabs



APPLICATOR SETUP TAB

The Applicator Setup Tab provides options to create a new, edit, or remove an applicator. This tab also provides a summary to the section configuration. For more information on the Precision Farming Setup button, refer to Chapter 9, *Precision Farming*.

SYSTEM SETTINGS

The system settings provides many buttons that allow the user to modify the current configuration. The table below describes each button in detail.

TABLE 4. System Settings

Button	Description
Control Valve Setup	The Control Valve button allows the user to adjust the following settings for each product: <ul style="list-style-type: none"> • Valve Response Rate • Control Deadband • Valve Delay • Valve Advance • Control Effort
Rate Sensor Setup	The Rate Sensor Setup button provides the options to adjust the following settings: <ul style="list-style-type: none"> • Flow Meter Calibration • Flow Meter Pulse/Units • Flow Meter Low Limit • Tank Fill Flow Meter Calibration • Tank Fill Flow Meter Pulse/Units There is also the option to perform a catch test and applied product calibration.
Tank Fill Settings	This button allows the user to enter the Tank Capacity, Current Tank Level, and Low Tank Level.
Display Setup Menu	The Display Setup Menu allows the user to customize the main run screen object pool.
Pressure Sensor Setup	This button allows the user to modify the alarm Min and Max for any products that have pressure alarms selected.
Auxiliary Functions	The Auxiliary Functions button allows the user to create new or modify existing auxiliary functions.
Scale Setup	Scale Setup allows the user to configure scale options.

ALARM SETTINGS

Press the Alarm Settings tab to modify or update alarm settings such as Off Rate Alarm and the Minimum Flow Rate. There is also an option to update the Pressure Alarm.

RATES SETUP

The Rates Setup tab allows the user to adjust the Preset Rate Values, Rate Bump, Rate Selection, and other values entered during the original configuration.

FEATURE UNLOCKS

If there are additional features available for the RCM, enter the provided Activation Key to access these features.

TOTALS

The totals button provides options to access a Current Totals, Device totals, and Distance totals tabs.

DIAGNOSTICS

Selecting the Diagnostics button open a window with tabs for the items listed below.

SYSTEM INFORMATION

Displays information about the RCM including the Hardware Serial Number, Hardware Revision, and Software Version Number.

TESTS

The Tests tab allows the user to select various tests from a dropdown. These list of tests will vary by product configuration.

DIAGNOSTIC TROUBLE CODES

This tab lists Active and Inactive diagnostic trouble codes as well as the ability to Clear the active codes.

SYSTEM SUMMARY

Displays information configured during the setup process but does not provide the option to modify the configuration.


PRODUCT SUMMARY

The Product Summary provides a brief summary for all of the products such as Application Type, Control Valve type, Target Rate, and other settings. This tab does not allow the user to modify the configurations.

AUXILIARY DRIVERS

Auxiliary drivers that were created during configuration are listed in Auxiliary Drivers.

FIGURE 27. Auxiliary Drivers



To give the driver a custom name, press in the Driver Name field and, using the keypad, enter the desired name. To activate the auxiliary driver, select the driver number button next to the desired driver.

CHAPTER

PLANTER OPERATION

7

PLANTER MACHINE LIST

TABLE 1. RCM Machine List

Machine Type	Application Type	Application Mode	Application Mode Uses
• Planter	• Granular Seed	Planter Section Control	Controller interfaces with up to 16 (Level 1) or 32 (Level 3) planter sections. Multiple row clutches can be grouped for each section. Seed rate is manually controlled via ground drive transmission.
• Seeder	• Granular Seed	Seed Rate Control with Clutches	Controller interfaces with up to 4 hydraulic motor drives for seed rate control and up to 24 planter sections. Multiple row clutches can be grouped for each section.
		Seed Rate Control without Clutches	Controller interfaces with up to 16 electric or hydraulic motor drives for seed rate and section control. Multiple rows can be grouped for each hydraulic motor drive.

PLANTER SETUP

There are three possible types on planter configurations. There is a wizard section listed below for each possible configuration.

SECTION CONTROLLED PLANTER SETUP

1. Select Planter as the machine type.

FIGURE 1. Name Profile

The screenshot shows a 'Name Profile' configuration window. It contains the following fields and values:

- Profile Name: Planter
- Machine Type: Planter
- Application Width: 40.000 (ft)
- Software Version Number: 1.3.0.5
- Hardware Serial Number: 1062

At the bottom, there is a 'RAVEN' button and a blue arrow button pointing right.

2. Enter the Application Width.
3. Press Next.
4. Enter the Number of Sections, Row Spacing, and the Number of Rows. The Number of Rows x Row Spacing must equal the Application Width entered in step 2.

FIGURE 2. Setup Selections

The screenshot shows a 'Setup Sections' configuration window. It contains the following fields and values:


- Number of Sections: 8
- Row Spacing: 30
- Number of Rows: 16
- Divide Evenly:

At the bottom, there is a 'RAVEN' button and a blue arrow button pointing right.

NOTE: The number of total sections depends on task controller capability.

5. If you did not select Evenly Divide, enter the number of rows per section. The Planter run screen will open.


FIGURE 3. Setup Section Width



SEED RATE CONTROL WITH CLUTCHES PLANTER SETUP

6. Set the appropriate ECU # from the drop-down. This is used to identify, prioritize, and sort RCMs when multiple RCMs are on the same system. For systems with a single RCM, set this to "1".

FIGURE 4. Setup System



7. Enter the desired number in the Number or Products field.
8. Press Next.
9. Select the desired Application Type for the product.

FIGURE 5. Setup Application Type




10. Press Next.
11. Select the Application Mode for Product 1.

FIGURE 6. Setup Application Type



12. Press Next.
13. Configure the Number of Sections, Row Spacing, Number of Drives, and Number of Rows. If desired, select the Divide Evenly checkbox to automatically divide the sections widths.

FIGURE 7. Setup Sections





14. Press Next.

15. Repeat Figure 9 on page 99 through Figure 13 on page 100 for all products.

NOTE: On the Setup Sections Harnessing screen for additional products, enter the next lowest number not being used by the previous section group. For example, if the first product is using the first eight sections, start the second product on section 9.

16. After completing the product configurations, enter the information on the Setup Sections Width screens.


FIGURE 8. Setup Section Width Screens



17. Press Next.


18. Select one of the Auxiliary Driver drop downs on the Setup Auxiliary Drivers page. Auxiliary drivers are additional switches that provide a 12V signal to a device.

FIGURE 9. Setup Auxiliary Drivers




19. Press Next.
20. Select the checkbox next to the desired Latched Aux Output. Latched means that, once selected, the signal remains constant until the button is pressed again. Leaving the checkbox unselected means that the signal is only active when the button is held.

FIGURE 10. Auxiliary Driver Drivers



21. Press Next.
22. On the Setup Pressure Sensors page, select the appropriate Pressure Sensors for each product from the dropdown.


FIGURE 11. Setup Pressure Sensors



23. Press Next.

24. Use the check boxes on the Setup Pressure Driver screen to select a Product for the first pressure sensor.

FIGURE 12. Setup Pressure Drivers




25. Press Next.

26. Repeat Figure 24 on page 103 and Figure 25 on page 103 for all pressure sensors.

27. If desired, configure the alarms for each pressure sensor on the Setup Pressure Alarms screen.

FIGURE 13. Setup Pressure Alarms



28. Press Next.

29. On the Setup Control Valve page configure the Control Valve Type, Valve Response Rate, and Control Deadband for the first product. If desired, select the Enable PWM Smart Control checkbox.

FIGURE 14. Setup Control Valve



30. Press Next.

31. On the Setup PWM page, configure the Coil Frequency, PWM High Limit, PWM Low Limit, and PWM Startup for the first product.

FIGURE 15. Setup PWM



32. Press Next.

33. Configure the Seeds/Revolution, Motor/Meter Ratio, and Pulses/Revolution on the first Setup Rate Sensor Page.

FIGURE 16. Setup Rate Sensor



34. Press Next.

35. Enter the Preset Rate Values, Rate Bump, and Rate Selection on the Setup Rates page. If desired, select the Display Smoothing Checkbox.

FIGURE 17. Setup Rates

Setup Rates

Product 1 Planter ?

	Rate 1	Rate 2	Rate 3
Preset Rate Values (k seed/ac)	30.0	35.0	40.0
Rate Bump (k seed/ac)	2.0		
Rate Selection	Predefined or Rx		
Display Smoothing	<input checked="" type="checkbox"/>		

RAVEN

36. If desired, enter the Off Rate Alarm percentage and enable the Alarm checkbox.

FIGURE 18. Setup Alarms

Setup Alarms

Product 1 Planter ?

Off Rate Alarm (% off target rate) 20 Alarm?

RAVEN

37. Press Next.

38. Repeat Figure 29 on page 104 through Figure 37 on page 106 for each product. Product configuration will vary depending on application type.

39. After all products are configured, a Setup Summary page will open displaying information about the configuration. If needed, press back to adjust the configurations. If the setup seems correct, press Next. The run page home screen will open. For additional information on the run page, refer to "Planter Run Page Overview" on page 116.

SEED RATE CONTROL WITHOUT CLUTCHES PLATER SETUP

1. Select Planter from the dropdown on the Select Profile Page.

FIGURE 19. Name Profile

2. Press Next.
3. Set the appropriate ECU # from the drop-down. This is used to identify, prioritize, and sort RCMs when multiple RCMs are on the same system. For systems with a single RCM, set this to "1".

FIGURE 20. Setup System

ECU S/N	ECU #	Number of Products
RCH-1039	[Dropdown]	[Input] ?

4. Enter the desired number in the Number or Products cell.
5. Press Next.
6. Select the desired Application Type for the product.

FIGURE 21. Setup Application Type



7. Press Next.
8. Select the Application Mode for Product 1.

FIGURE 22. Setup Application Type




9. Press Next.
10. Configure the Number of Sections, Row Spacing, Number of Drives, and Number of Rows. If desired, select the Divide Evenly checkbox to automatically divide the sections widths.

FIGURE 23. Setup Sections



11. Press Next.
12. If necessary, select the Application Mode for additional products.
13. Press Next.
14. On the Setup Section Groups screen, select the Number of Section Groups from the dropdown.

FIGURE 24. Setup Section Groups



15. Press Next.
16. Review the information on the Setup Section Harnessing screen.
17. Press Next.
18. On the Setup Section Harnessing screen, enter the Starting Section Number, Number of Sections, and select Equal Section Widths (if desired).

FIGURE 25. Setup Section Harnessing



19. Press Next.

20. Select the Section Group assignment for each product from the dropdown on the Setup Section Group Assignment screen.


FIGURE 26. Setup Section Group Assignment



21. Press Next.

22. After completing the product configurations, enter the information on the Setup Sections Width screens.


FIGURE 27. Setup Section Width Screens



23. Press Next.

24. If desired, select Setup Auxiliary Drivers. Auxiliary drivers are additional switches that provide a 12V signal to a device.


FIGURE 28. Setup Auxiliary Drivers



25. Press Next.

26. Select the checkbox next to the desired Latched Aux Output. Latched means that, once selected, the signal remains constant until the button is pressed again. Leaving the checkbox unselected means that the signal is only active when the button is held.


FIGURE 29. Auxiliary Driver Assignments



27. Press Next.

28. On the Setup Pressure Sensors page, select the appropriate Pressure Sensors for each product from the dropdown.


FIGURE 30. Setup Pressure Sensors



29. Press Next.

30. Use the check boxes on the Setup Pressure Assignment screen to select a Product for the first pressure Sensor.

FIGURE 31. Setup Pressure Assignments




31. Press Next.

32. Repeat Figure 24 on page 103 and Figure 25 on page 103 for all pressure sensors.

33. If desired, configure the alarms for each pressure sensor on the Setup Pressure Alarms screen.

FIGURE 32. Setup Pressure Alarms



34. Press Next.

35. On the Setup Control Valve page configure the Control Valve Type, Valve Response Rate, and Control Deadband for the first product. If desired, select the Enable PWM Smart Control checkbox.

FIGURE 33. Setup Control Valve



36. Press Next.

37. On the Setup PWM page, configure the Coil Frequency, PWM High Limit, PWM Low Limit, and PWM Startup for the first product.

FIGURE 34. Setup PWM



38. Press Next.

39. Configure the Seeds/Revolution, Motor/Meter Ratio, and Pulses/Revolution on the first Setup Rate Sensor Page.


FIGURE 35. Setup Rate Sensor



40. Press Next.

41. Enter the Preset Rate Values, Rate Bump, and Rate Selection on the Setup Rates page. If desired, select the Display Smoothing Checkbox.

FIGURE 36. Setup Rates



42. If desired, enter the Off Rate Alarm percentage and enable the Alarm checkbox.

FIGURE 37. Setup Alarms




- 43. Press Next.
- 44. Repeat Figure 29 on page 104 through Figure 37 on page 106 for each product. Product configuration will vary depending on application type.
- 45. After all products are configured, a Setup Summary page will open displaying information about the configuration. If needed, press back to adjust the configuration. If the setup seems correct, press Next. The run page home screen will open. For additional information on the run page, refer to "Planter Run Page Overview" on page 116.

PLANTER RUN PAGE OVERVIEW

The image below is an example of a typical run screen.

FIGURE 38. Planter Run Screen



PRODUCT TABS

Press on the product tab to select the desired product. This will open the to product run screen for that product.

CURRENT PRODUCT RUN SCREEN

The current product run screen displays information for the selected product. Each product run screen will vary based on product configuration.

Data Fields display selected settings and can be changed to the operator's preferences.

FIGURE 39. Planter Run Screen





TABLE 2. Planter Run Screen Information

	Button	Description	Function/Operation
	1	Voltage	Indicates the current duty cycle.
	2	Injection Pressure	Indicates the injection pressure.
	3	Seed Level	Displays the current bin level.
	4	Acres Applied	Displays the number of acres applied since starting the job.
	5	Section Switchbox Button	Indicates if the switch box is on or off: <ul style="list-style-type: none"> • Green - On • Red - Off Press the switch box button to navigate to a screen that allows the user to turn off the switch boxes for individual sections.
	6	Actual Rate	Displays the actual application rate.
	7	Target Rate	Displays the current target rate. The target rate can be adjusted by pressing in the number cell and entering a new number.
	8	Manual/Automatic Toggle	Press this to switch between manual and automatic operation.
	9	Product On/Off Toggle	Press this to manually turn a product on or off.
	10	Rate Bump Down	Press this to decrease the application rate at the increment set during configuration.
	11	Rate Bump Up	Press this to increase the application rate at the increment set during configuration.
	12	Application Rate	Displays the current application speed in acres per hour.
	13	Product Tab	Select a tab to view information for that product.

	Button	Description	Function/Operation
	14	Quick Start Button	Press the quick start button to quickly configure a product.
	15	Master Switch Indicator	The Master Switch Indicator shows the status of the master switch. <ul style="list-style-type: none"> • Green - On • Red - Off • Orange - Cycle the master switch
	16	Row Number	Displays the ending row number for the section.
	17	Row Indicator	Displays the row status. <ul style="list-style-type: none"> • Gray - Off • Green - On
	18	Meter Spread High and Low	Indicates the meter spread speed in RPM.
	19	Traveling Speed	Shows the implement/ machine speed.


MAIN

Press main at any time to return to the Current Product Run Screen.

SETUP

Pressing setup opens a screen with many tabs.

FIGURE 40. Setup Tabs



APPLICATOR SETUP TAB

The Applicator Setup Tab provides options to create a new, edit, or remove an applicator. This tab also provides a summary to the section configuration. For more information on the Precision Farming Setup button, refer to Chapter 9, *Precision Farming*.

SYSTEM SETTINGS

The system settings provides many buttons that allow the user to modify the current configuration. The table below describes each button in detail.

TABLE 3. System Settings

Button	Description
Control Valve Setup	The Control Valve button allows the user to adjust the following settings for each product: <ul style="list-style-type: none"> • Valve Response Rate • Control Deadband • Valve Delay • Valve Advance • Control Effort
Rate Sensor Setup	The Rate Sensor Setup button provides the options to adjust the following settings: <ul style="list-style-type: none"> • Flow meter Calibration • Flow meter Pulse/Units • Flow meter Low Limit • Tank Fill Flow meter Calibration • Tank Fill Flow meter Pulse/Units There is also the option to perform a catch test and applied product calibration.
Tank Fill Settings	This button allows the user to enter the Tank Capacity, Current Tank Level, and Low Tank Level.
Display Setup Menu	Use the Display Setup Menu to add buttons, remove buttons, or reorganize the main run screen.
Pressure Sensor Setup	This button allows the user to modify the alarm Min and Max for any products that have pressure alarms selected.
Auxiliary Functions	The Auxiliary Functions button allows the user to create new or modify existing auxiliary functions.
Scale Setup	Scale Setup allows the user to configure scale options.

ALARM SETTINGS

Press the Alarm Settings tab to modify or update alarm settings such as Off Rate Alarm and the Minimum Flow Rate. There is also an option to update the Pressure Alarm.

RATES SETUP

The Rates Setup tab allows the user to adjust the Preset Rate Values, Rate Bump, Rate Selection, and other values that were entered during the original configuration.

FEATURE UNLOCKS

If there are additional features available for the RCM, enter the provided Activation Key to access these features.

TOTALS

The totals button provides options to access a Current Totals, Device totals, and Distance totals tabs.

DIAGNOSTICS

Selecting the Diagnostics button open a window with tabs for the items listed below.

SYSTEM INFORMATION

Displays information about the RCM including the Hardware Serial Number, Hardware Revision, and Software Version Number.

TESTS

The Tests tab allows the user to select various tests from a dropdown. These list of tests will vary by product configuration.

DIAGNOSTIC TROUBLE CODES

This tab lists Active and Inactive diagnostic trouble codes as well as the ability to Clear the active codes.

SYSTEM SUMMARY

Displays information configured during the setup process but does not provide the option to modify the configuration.


PRODUCT SUMMARY

The Product Summary provides a brief summary for all of the products such as Application Type, Control Valve type, Target Rate, and other settings. This tab does not allow the user to modify the configurations.

AUXILIARY DRIVERS

Auxiliary drivers that were created during configuration are listed in Auxiliary Drivers.

FIGURE 41. Auxiliary Drivers



To give the driver a custom name, press in the Driver Name field and, using the keypad, enter the desired name. To activate the auxiliary driver, select the driver number button next to the desired driver.

CHAPTER

8

STAND ALONE SCALE OPERATION

SCALE MACHINE LIST


TABLE 1. RCM Machine List

Machine Type	Application Type	Application Mode	Application Mode Uses
•Scale	•NA	NA	NA

STAND ALONE SCALE OPERATION


1. Select Scale as the Machine Type.

FIGURE 1. Name Profile




2. Enter a Profile Name.
3. Press Next.
4. Select the check box(es) next to the desired Scale(s) you want to monitor.

FIGURE 2. Scale Setup




5. If desired, select the Total Scale checkbox to monitor the weight of all the selected scales combined.
6. Press Next.
7. Enter the Scale Total Calibration Number.

FIGURE 3. Scale Setup



8. Press Next.
9. Review the scale configuration on the Setup Summary page.

FIGURE 4. Setup Summary




10. If any of the information is correct, press back to adjust the configuration. If the configuration is correct, press Next.

SCALE RUN PAGE OVERVIEW

The image below is an example of a typical run screen.

FIGURE 5. RCM Main Screen



SCALE SCREEN

The scale screen displays graphic and numeric representations of the scales as well as options to zero a scale or view the current gross scale weight.

CURRENT PRODUCT RUN SCREEN

The current product run screen displays information for the selected product. Each product run screen will vary based on product configuration.

Data Fields display selected settings and can be changed to the operator's preferences.

FIGURE 6. Air Cart Run Screen




TABLE 2. Scale Run Screen Information

	Button	Description	Function/Operation
	1	Scale Selection	Press these buttons along to the to switch between the different scales.
	2	Weight	Displays the current weight on the selected scale.
	3	Tare	Press the Tare button to zero out the selected scale. If the combined weight scale is selected this will display as Zero.
	4	Scale Graphics	Shows a graphical representation of the weight of teach scale.
	5	Gross	Displays the weight on the scale. If the combined weight scale is selected this will display as Net.
	6	Combined Weight	Displays the combined weight of all the scales.


MAIN

Press main at any time to return to the Current Product Run Screen.

SETUP

Pressing setup opens a screen with many tabs.

FIGURE 7. Setup Tabs



APPLICATOR SETUP TAB

The Applicator Setup Tab provides options to create a new, edit, or remove an applicator. This tab also provides a summary to the section configuration.

SYSTEM SETTINGS

The system settings provides many buttons that allow the user to modify the current configuration. The table below describes each button in detail.

TABLE 3. System Settings

Button	Description
Control Valve Setup	The Control Valve button allows the user to adjust the following settings for each product: <ul style="list-style-type: none"> • Valve Response Rate • Control Deadband • Valve Delay • Valve Advance • Control Effort
Rate Sensor Setup	The Rate Sensor Setup button provides the options to adjust the following settings: <ul style="list-style-type: none"> • Flow Meter Calibration • Flow Meter Pulse/Units • Flow Meter Low Limit • Tank Fill Flow Meter Calibration • Tank Fill Flow Meter Pulse/Units There is also the option to perform a catch test and applied product calibration.
Tank Fill Settings	This button allows the user to enter the Tank Capacity, Current Tank Level, and Low Tank Level.
Display Setup Menu	The Display Setup Menu allows the operator to configure the main run screen.
Pressure Sensor Setup	This button allows the user to modify the alarm Min and Max for any products that have pressure alarms selected.
Auxiliary Functions	The Auxiliary Functions button allows the user to create new or modify existing auxiliary functions.
Scale Setup	Scale Setup allows the user to configure scale options.

FEATURE UNLOCKS

If there a additional features available for the RCM, enter the provided Activation Key to access these features.

TOTALS

The totals button provides options to access a Current Totals, Device totals, and Distance totals tabs.

DIAGNOSTICS

Selecting the Diagnostics button open a window with tabs for the items listed below.

SYSTEM INFORMATION

Displays information about the RCM including the Hardware Serial Number, Hardware Revision, and Software Version Number.

TESTS

The Tests tab allows the user to select various tests from a dropdown. These list of tests will vary by product configuration.

DIAGNOSTIC TROUBLE CODES

This tab lists Active and Inactive diagnostic trouble codes as well as the ability to Clear the active codes.

SYSTEM SUMMARY

Displays information configured during the setup process but does not provide the option to modify the configuration.


PRODUCT SUMMARY

The Product Summary provides a brief summary for all of the products such as Application Type, Control Valve type, Target Rate, and other settings. This tab does not allow the user to modify the configurations.

AUXILIARY ASSIGNMENTS

Auxiliary assignments that were created during configuration are listed in Auxiliary Assignments.

FIGURE 8. Auxiliary Assignments



To give the driver a custom name, press in the Driver Name field and, using the keypad, enter the desired name.

To activate the auxiliary driver, select the driver number button next to the desired driver.


Precision farming allows the user to modify configurations that may not be available through the field computer.

IMPORTANT: Depending on the field computer, these settings may or may not be implemented.

To adjust precision farming settings after performing a machine configuration:

1. Press Setup.

FIGURE 1. RCM Settings



2. Select Precision Farming Setup.
3. Review the information on the Section Setup Wizard screen then press Next.

FIGURE 2. Section Setup Wizard




4. Enter a Product Delay value for every product. Product Delay is the amount of time the product needs to adjust when changing rate zones using a prescription map.

FIGURE 3. Setup Product Delay



5. Press Next.
6. Select Rear Implement if it is a rear mounted implement.

FIGURE 4. Section Offsets



7. Select Left of Center of the implement is mounted left of center.
8. Select Individual Sections Fore/Aft Offsets if different sections for the same product have different fore and aft locations.
9. Enter the value for the Left/Right Offset.
10. Enter the Distance from Pivot Point to Application Point value.

NOTE: The pivot point is the point where the implement turns. Typically this is the wheels.

11. Enter the Distance from Connection point to Implement Pivot Point value.
12. Press Next.
13. If applicable, check Individual Section On/Off Times if different sections will need different look ahead times. For example, the center sections of an air cart will need shorter look ahead times than the outer sections.


NOTE: Not all field computers support Individual Section On/Off Times.

FIGURE 5. Section Turn On/Off Times



- 14. Press Next.
- 15. If Individual Section On/Off Times was selected, configure the Section Turn On/Off Times for the Section Group. If not, skip to step 16.

FIGURE 6. Section Turn On/Off Times



- 16. Press Next.
- 17. If applicable, enter the offset values for individual sections. If the section is located in front of the implement pivot point, enter it as a negative value.

FIGURE 7. Individual Fore/Aft Offsets

Individual Fore/Aft Offsets

Section Group 2

7' (in) 0

8' (in) 0

5' (in) 0

6' (in) 0

RAVEN

18. Press Next.

19. Repeat step 6 through step 18 for all section groups.

20. After configuration is complete, press Next and the Application Setup screen will display again.

ACCESSING SYSTEM INFORMATION

1. Select the Diagnostics button.
2. Select the System Information tab.



3. Select the desired page from the drop-down.

Option	Description
Hardware/Software	Displays the manufacturer's information for the Raven Rate Control Module hardware and software.
Switchbox	Displays if an external switchbox is present and the status of the switches.
Delivery System	Shows application information for the selected product.
Section Status	Shows if each section valve is currently open or closed.
System Voltages	Shows voltage and current information for the Raven Rate Control Module.
Working Parameters	Displays the implement width, current speed, and speed source.
Switches/Status	Displays the status of the Master switch.
Pressure Sensors	Displays voltage and pressure information for each pressure sensor.
Bin Level Sensors	Displays whether each bin level sensor is covered or uncovered.
RPM Sensors	Shows the signal detected by each RPM sensor.
Tank Fill Monitor	Displays the fill rate and volume detected by the tank fill monitor.
Task Totals	Shows the area covered and volume applied for the current task.
Turn Compensation	Displays inertial sensor information.
Speed Source	Displays available and active speed source

Option	Description
Funnel Actuator Positions	Displays target and actual positions.
ISOBUS Short Cut Button	Displays the ISB status.

GENERAL TROUBLESHOOTING

Symptom	Problem	Solution
Unexpected application rate.	Incorrect rate type selected (gal/min or gal/acre).	Select the correct rate type.
Product does not shut off.	Valve does not respond to commands.	Select the correct valve type.
2-Wire valve selection is not available.	Dual boom is selected.	Disable dual boom.
	More than seven sections are selected.	Assign fewer than eight sections.
Implement section is not turning on or off.	Incorrect section valve type selected.	Select correct section valve type.
Application is erratic.	Calibration number is not set correctly.	Enter the correct calibration number.
Trouble code is displayed for high pressure.	System pressure is too high.	Select flow return in the system setup.
Trouble code is displayed for unexpected flow.	Constant flow is disabled when using a constant flow system with boom valve closed.	Select constant flow in system setup.
Flow is not applying at desired rate.	Incorrect application rate.	Ensure 10 gal/10L unit is used.
	Minimum Flow rate feature causes over-application in areas where machine speed is low enough to activate Minimum Flow Rate.	Set minimum flow rate to zero to disable feature.
System detects implement is down for an extensive period of time.	Height switch is disabled.	If height switch indicator does not match machine operation, service height switch.
Unexpected chemical flow detected.	Controller attempts to close section valves, but detects flow on a sprayer or liquid fertilizer system.	Shut off solution pump.
Unable to setup minimum and maximum alarms.	Minimum and maximum alarms are disabled.	Ensure pressure sensor is installed and configured.
Unable to set values.	System not allowing changes values or settings.	Ensure Master Switch is off.
Unexpected anhydrous ammonia flow detected.	Controller attempts to close On/Off valve, but still detects flow.	Select button to turn off control valve.
	Controller attempts to close all valves, but still detects flow.	Follow instructions on Warning page on display.
Pressure sensors are not configured.	Pressure sensor 2 is not an option.	Ensure both sensors are configured.
Not able to activate system.	Master Switch indicator is orange.	Cycle master switch.
Unwanted minimum flow rate activation.	Over application in low speed areas.	Set minimum flow rate to zero to disable function.

TESTS

1. Navigate to the Raven Rate Control Module.
2. Select Diagnostics button.
3. Select the Tests tab.



4. Select the test from the drop-down menu.
 - a. Liquid Diagnostics Test Warning displays after selecting any of the following liquid application:
 - Nozzle Flow Check
 - Rinse Cycle
 - Control/Section Test
 - Control Valve Test
 - Calibrate PWM Limits



- b. NH_3 Diagnostics Test Warning displays after selecting any of the following for NH_3 applications:
 - Energize System

- Bleed System Test



NOTE: The bleed system test will not evacuate all of the NH_3 entirely. Perform the manual bleed procedure for the system to ensure NH_3 is completely evacuated.

- c. Dry Diagnostic Test Warning displays after selecting any of the following for dry applications:
- Granular Flow Check

NOTE: If spinners of running then conveyor speed has to be limited and back covers must be removed.

- Spreader/Air Cart Check
- Control/Section Test
- Calibrate PWM Limit
- Bin/Tank Cleanout
- Actuator



5. Read the Discharge Warning and select Accept.

NOZZLE FLOW CHECK

IMPORTANT: Always fill solution tank with clean water to perform nozzle flow check.

NOTE: Enter conditions that are comparable to normal operation. Larger dispensed volumes result in longer but more accurate calibration tests.

Perform Nozzle Flow Check to test an application rate at a desired speed without the machine moving. The following items can be determined:

- If actual application rate meets the target application rate at a given speed.
- The actual flow rate of an implement section.
- Whether the nozzles are worn.
- Spray control valve pressure at a desired speed and application rate.

NOTE: Turn the master switch off or leave Diagnostics at any time to cancel the test.

Speed and rate can be changed while the test is running.

1. Enter a Test Speed and Rate.



2. Turn the master switch on.
3. Select Start.

If the volume is higher than expected and pressure is lower than expected, nozzle tips could be worn.

If pressure is higher than expected for the given output, nozzle tips could be partially plugged. Pressure drops can occur between section shutoff valves and nozzle tips. This is normally only associated with high flow rates.

RINSE CYCLE

IMPORTANT: Always fill the solution tank with clean water to perform the rinse cycle.

Rinse Cycle test fully opens all sections, fence row valves, and flow control valve until the flow meter detects reduced flow.

NOTE: Turn the master switch off or leave Diagnostics at any time to cancel the test.



1. Turn the master switch on.
2. Select Start.

CONTROL/SECTION TEST

Selected sections open while the test is in progress. Unselected sections remain closed.

NOTE: Turn the master switch off or leave Diagnostics at any time to cancel the test.

1. Enable the desired sections.
2. Turn the master switch on.




3. Select Start.
4. Toggle section on or off using the buttons.
5. Press and hold - or + to operate the control valve.

CONTROL VALVE TEST

This test operates control valve without dispensing product.

NOTE: Turn the master switch on or leave the Diagnostics at any time to leave the test.



1. Select Start.
2. Press and hold - or + to operate the control valve.

CALIBRATE PWM LIMITS

NOTE: Turn master switch off or leave Diagnostics at any time to cancel the test.

1. Turn the master switch on.




2. Press Start.
3. Press and hold - or + buttons until the minimum acceptable flow/pressure is achieved.
4. Select Set Low Limit.
5. Press and hold the - or + buttons until the maximum acceptable flow/pressure is achieved.
6. Select Set High Limit.

ENERGIZE SYSTEM

NOTE: Turn the master switch off or leave diagnostics page to immediately force the valves to return to the closed position and stop flow.

Use the Energize System procedure to test for flow at openers, purge air and vapor from the NH₃ delivery system, and fill cooler and hoses with liquid anhydrous. Select Start to fully open the control valve and section valves for a few seconds and then automatically close the valves.

1. Ensure the area is clear of people, pets, and livestock.
2. Position the machine into the wind.
3. Turn the master switch on.




4. Select the Override Height Switch checkbox.
5. Select Start. The valves will stay open for a few seconds.
6. Repeat the procedure if needed.

BLEED SYSTEM TEST

NOTE: Turn the master switch off or leave diagnostics page to immediately force the valves to return to the closed position and stop flow.

The Bleed System Test allows the operator to bleed trapped anhydrous ammonia from high-pressure lines between section valves and control valves while remaining seated in the cab.

1. Bleed and disconnect the nurse tank and supply lines.
2. Ensure that the area is clear of people, pets, and livestock.
3. Position the machine into the wind.
4. Enable the desired sections.



5. Select the Override Height Switch checkbox.
6. Select Start.
7. Toggle the sections as needed.

NOTE: Turn the master switch on or leave the Diagnostics at any time to leave the test.

SPREADER/AIR CART CHECK

NOTE: Turn the master switch off or leave Diagnostics at any time to cancel test.

1. If the system is configured with an RPM assignment, the RPM assignment will be disabled for this test. If desired, select the Enable RPM Products check box.



2. Enter the Test Speed and Rate.



3. Turn the master switch on.
4. Select Start.

BIN/TANK CLEANOUT

NOTE: Turn the master switch off or leave Diagnostics at any time to cancel the test.

1. Select Product bins or tanks to be cleaned out.



2. Turn the master switch on.
3. Select Start.

NOTE: Conveyor speed must be limited and back covers removed.

DEMONSTRATION MODE


Demonstration Mode provides a bench top simulation only. It is not intended for use on actual equipment.

1. Select Demonstration Mode from the Tests tab. A warning prompt will appear.
2. Read the warning and either select Cancel or Accept.



3. After the Demonstration Mode screen opens, select the Flow Simulation type.
 - None: No flow will be simulated.
 - Fixed Freq: If Fixed Frequency is selected a Fixed Flow box will appear. Enter the desired flow value in the box.

- Rate Tracking: The system will adjust flow so it matches the flow required to achieve the target application rate entered on the main screen.



4. Enter a simulated pressure value for pressure sensors 1, 3, and 5. Enable the checkbox.
5. Enter a simulated pressure value for pressure sensors 2, 4 and 6. Enable the checkbox.


DIAGNOSTIC LOOP BACK TEST

Loop back tests provide a way to self-test the Raven Rate Controller. There are two loop back tests available.

- ECU Test: The ECU Test performs a test of the Raven Rate Controller Module.
- 47 Pin: The 47 Pin test performs a test of the Raven Rate Controller Module and the cabling and pins of the product cable. This test requires a 47 pin loop back tester.

To perform a Diagnostic Loop back Test:

1. Ensure the Master Switch is off and the 47-pin plug of the product cable is disconnected.
2. Select the Tests tab.




3. Select Diagnostics Loop Back Test from the test selection drop down.

4. Press Begin. A Warning window will open checking if the product cable is disconnected.




5. Press Accept to continue or Cancel to exit the test. After pressing Accept, the Diagnostic Loop Back Test window will open.




6. Review the information on the Diagnostic Loop Back Test.
7. Select the desired test (47 Pin or ECU Test) from the Test Selection drop down.
8. If desired, select the checkbox by Continuous Test. This checkbox will make the test run repeatedly until the Stop button is pressed.
9. After the desired test is selected, press Start. The Diagnostic Loop Back Test progress window will open. This window shows the test status and the number of tests that Pass or Fail. If the Continuous Test checkbox was

not selected the test will run one time. If the Continuous Test checkbox was selected, the test will repeat until the Stop button is pressed.

NOTE: The Start button will be grayed out if the product cable is connected or the master switch is on. Fix the issue to start the test.



10. If a failure is detected a Loop Back Failure Alert window will open. After reviewing the information of the Alert, select Accept.



11. After the loop back test is complete, press Accept to return to the test selection window. To exit the loop back test, select the cancel button.



12. Select the Accept button to exit the test or Cancel to return to the test.

13. Select the desired object pool.

DIAGNOSTIC LEDES

There are four LEDs on the front of the ECU, labeled with the power symbol, A, B, and C. Each LED's color and blink rate indicates different information as detailed in the table below. If multiple states are true for a given LED the first active state listed in the table will be the state displayed. After addressing the displayed state (if needed), the next LED state will be indicated.

FIGURE 1. Raven Rate Controller LEDs



LED	Main App Controlled	Color	Blinks Per Second	Status Name	Description
Power	No	GREEN	Solid	ECU powered	Active when ECU has power

LED	Main App Controlled	Color	Blinks Per Second	Status Name	Description
A	No	OFF	Solid	Microprocessor Off	Active when the microprocessor is not powered
	No	ANY	Solid	System Fault	Active when the microprocessor has stopped functioning
	No	YELLOW	1	Boot Hold Mode	Active when the boot loader enters boot hold mode
	No	RED	5	Programming Microprocessor	Active when the microprocessor is being programmed
	Yes	RED	1	ISOBUS Offline	Active if the ISOBUS is offline
	Yes	WHITE	1	UT Offline	Active if the UT is offline
	Yes	PURPLE	1	Loop back Test Mode	Loop back test mode enabled
	Yes	GREEN	1	Systems Normal	Active when linked with UT and system is normal
B	No	RED	Solid	FPGA not running	PCB subsystem not running (FPGA)
	Yes	RED	1	ECU Power Loss	System has lost ECU power
	Yes	BLUE	1	Rate Sensor Signal Present	Signal is present on 1 or more rate sensors
	Yes	YELLOW	1	DTC Active	One or more DTCs are active
	Yes	WHITE	1	System Under Voltage	System voltage is below 11.5 volts
	Yes	PURPLE	1	System Over Voltage	System voltage is above 16 volts
	Yes	BLUE	Solid	Product Enabled	One or more product switches have been set to On
	Yes	PURPLE	Solid	RPM Signal Present	Signal is present on one or more RPM sensors
	Yes	GREEN	Solid	All Products Disabled	All product switches have been set to Off
	Yes	RED	Solid	Current loopback test sequence failure	One or more loop back subtests failed in this current test sequence
	Yes	YELLOW	Solid	Previous loop back test sequence failure	One or more loop back subtests failed in the previous test sequence
	Yes	GREEN	Solid	No loop back subtests have failed	No loop back subtests have failed

LED	Main App Controlled	Color	Blinks Per Second	Status Name	Description
C	No	RED	Solid	FPGA not running	PCB subsystem not running (FPGA)
	Yes	BLUE	1	Bluetooth Command	Bluetooth command has been received
	Yes	BLUE	Solid	Bluetooth Comm Active	Bluetooth communication is active
	Yes	GREEN	1	Aux CAN Active	The Auxiliary CAN channel is active
	Yes	RED	1	Aux CAN Comm Lost	Active if the Auxiliary CAN channel was active and is now offline
	Yes	GREEN	Solid	LED C Functional - No Error	LED C is functional and there are no other LED C states to report
	Yes	PURPLE	Solid	Loop back test in progress	A loop back test is in progress
	Yes	GREEN	Solid	Loop back test not in progress	A loop back test is not in progress

OUTPUTS TABLE - SINGLE PRODUCT

NOTE: Enabling optional features, such as fence row nozzles and agitators reduces the number of section controls.

Output Number	3-Wire Section Valves	2-Wire Section Valves	NH ₃ Tool	Tiered Boom Applications
1	Section 1	Section 1 (+)	Section 1	Section 1
2	Section 2	Section 1 (+)	Section 2	Section 2
3	Section 3	Section 2(+)	Section 3	Section 3
4	Section 4	Section 2 (-)	Section 4	Section 4
5	Section 5	Section 3 (+)	Section 5	Section 5
6	Section 6	Section 3 (-)	Section 6	Section 6
7	Section 7	Section 4 (+)	Section 7	Section 7
8	Section 8	Section 4 (-)	Section 8	Section 8
9	Section 9	Section 5 (+) or agitator valve (+)	Boom pump (+)	Section 9
10	Section 10	Section 5 (-) or agitator valve (-)	Boost pump (-)	Section 10
11	Section 15 or agitator valve	Section 6 (+) or left fence row		Section 15 or agitator valve
12	Section 16 or flow return (+)	Section 6 (-) or right fence row		Section 16 or flow return (+)

Output Number	3-Wire Section Valves	2-Wire Section Valves	NH ₃ Tool	Tiered Boom Applications
13	Flow return (-) or left fence row	Section 7 (+) or flow return valve (-)	Master on-off valve	Section 17, tier 1 solenoid signal, flow return (-), or right fence row
14	Right fence row	Section 7 (-) or flow return valve (+)		Section 18, tier 2 solenoid signal, or left fence row
15	Control valve (+)	Control valve (+)	Control valve (+)	Control valve (+)
16	Control valve (-)	Control valve (-)	Control valve (-)	Control valve (-)
17	Section 11			Section 11
18	Section 12			Section 12
19	Section 13			Section 13
20	Section 14			Section 14
21				
22				
23				Section 19
24			Fast control valve power	Section 20
25	Flow return (+)	Section 8 (+) or agitator valve B (+)		Flow return (+)
26	Flow return (-)	Section 8 (-) or agitator valve b (-)		Flow return (-)
27			Section 9	
28	Agitator valve		Section 10	Agitator valve
29	Right fence row	Right fence row		Right fence row
30	Left fence row	Left fence row		Left fence row
31				
32				

OUTPUTS TABLE - MULTIPLE PRODUCTS

NOTE: Enabling optional features, such as fence row nozzles and agitators reduces the number of section controls.

Output Number	NH ₃ Tool	Spreader	Air Cart
1	Section 1	Section 1	Section 1
2	Section 2	Section 2	Section 2
3	Section 3	Section 3	Section 3
4	Section 4	Section 4	Section 4 or input 22
5	Section 5	Product 5 control valve (+) or spinner PWM (+)	Product 5 control valve (+), section 5 (primary), or master clutch (secondary)
6	Section 6	Product 5 control valve (-) or spinner PWM (-)	Product 5 control valve (-) or section 6 (primary)
7	Section 7		Input 21 or section 7 (primary)
8	Section 8		Master clutch (primary), section 8 (primary), or impute 10
9	Boost pump (+)	Product 4 control valve (+)	Product 4 control valve (+) or section 9 (primary)
10	Boost pump (-)	Product 4 control valve (-)	Product 4 control valve (-) or section 10 (primary)
11	Product 2 control valve (+)	Product 3 control valve (+)	Product 3 control valve (+) or section 15 (primary)
12	Product 2 control valve (-)	Product 3 control valve (-)	Product 3 control valve (-) or section 16 (primary)
13	Master on-off valve	Product 2 control valve (+)	Product 2 control valve (+)
14		Product 2 control valve (-)	Product 2 control valve (-)
15	NH ₃ control valve (+)	Product 1 control valve (+)	Product 1 control valve (+)
16	NH ₃ control valve (-)	Product 1 control valve (-)	Product 1 control valve (-)
17			Section 11
18			Section 12
19			Section 13
20			Section 14
21			
22			
23			
24	Fast control valve power		
25	Product 3 control valve (+)	Section 11	Next available section +6
26	Product 3 control valve (-)	Section 12	Next available section +7
27	Section 9	Section 5	Next available section
28	Section 10	Section 6	Next available section +1

Output Number	NH ₃ Tool	Spreader	Air Cart
29	Section 11	Section 7	Next available section +2
30	Section 12	Section 8	Next available section +3
31	Section 13	Section 9	Next available section +4
32	Section 14	Section 10	Next available section +5

INPUTS TABLE - SINGLE PRODUCT

NOTE: Enabling optional features, such as fence rows nozzles and agitators, reduces number of section controls.

Input Number	Sprayer and Liquid Fertilizer Tool	NH ₃ Tool
1	Flow meter signal	Flow meter signal
2	Fill flow meter signal	Master valve status
3		
4		
5		
6		Valve status 4
7		Valve status 5
8		Valve status 3
9		Valve power 1 sense
10		
11		Valve power 2 sense
12		
13		Valve status 1
14	Pressure signal 1 (boom pressure)	Pressure signal 1 (NH ₃ outlet)
15		Valve status 2
16	Pressure signal 2 (sparge pressure)	Pressure signal 2 (NH ₃ inlet)
17		
18		Pressure signal 3
19		Valve status 7
20		Valve status 8
21		
22		
23		Valve status 6
24	Pump RPM signal	Pimp RPM signal
25		
26		
27		

Input Number	Sprayer and Liquid Fertilizer Tool	NH ₃ Tool
28		Valve status 9
29		Valve status 10


INPUTS TABLE - MULTIPLE PRODUCT

Input Number	NH ₃	Spreader	Air Cart and Generic
1	Flow meter signal	Product 1 rate sensor signal	Product 1 rate sensor signal
2	Master valve status	Product 1 rate sensor signal (right-hand dual encoder)	Product 1 shaft sensor signal
3		Product 2 rate sensor signal	Product 2 rate sensor signal
4		Product 2 rate sensor signal (right-hand dual encoder)	Product 3 shaft sensor signal
5	Product 2 rate sensor signal	Product 3 rate sensor signal	Product 3 rate sensor signal
6	Valve status 4	Product 3 rate sensor signal (right-hand dual encoder)	Product 3 shaft sensor signal
7	Valve status 5	Product 4 rate sensor signal	Product 4 rate sensor signal
8	Valve status 3	Product 4 rate sensor signal (right-hand dual encoder)	Product 4 shaft sensor signal
9	Valve power 1 sense	Product 5 rate sensor signal	Product 5 rate sensor signal
10		Product 5 rate sensor signal (right-hand dual encoder) or pressure signal 5	Product 5 shaft sensor signal or pressure signal 5
11	Valve power 2 sense		
12	Pressure signal 6	Pressure signal 6	Pressure signal 6
13	Valve status 1	Product 1 bin level signal	Product 1 bin level signal
14	Pressure signal 1 (NH ₃ outlet)	Pressure signal 1 (primary)	Pressure signal 1 (primary)
15	Valve status 2	Product 2 bin level signal	Product 1 bin level signal
16	Pressure signal 2 (NH ₃ inlet)	Pressure signal 2 (primary)	Pressure signal 2 (primary)
17	Product 2 bin level signal	Product 3 bin level signal	Product 3 bin level signal
18	Pressure signal 3	Pressure signal 3 (primary)	Pressure signal 3 (primary)
19	Valve status 7	Product 2 bin level signal	Product 4 bin level signal
20	Valve status 8	Pressure signal 4 (primary)	Pressure signal 4 (primary)
21		Product 5 bin level signal	Product 5 bin level signal
22			
23	Valve status 6		Fan 2 PRM signal
24	Pump, fan, or spinner RPM signal	Fan or spinner RPM signal	Fan 1 RPM signal
25	Master switch	Master switch	Master switch
26	Implement height switch	Implement height	
27	Product 3 rate sensor signal	Pressure signal 4 (secondary)	Pressure signal 4 (secondary)
28	Valve status 9	Pressure signal 3 (secondary)	Pressure signal 3 (secondary)
29	Product 3 bin level signal or valve status 10	Pressure signal 2 (secondary)	Pressure signal 2 (secondary)

Input Number	NH ₃	Spreader	Air Cart and Generic
30	Pressure signal 4	Pressure signal 1 (secondary)	Pressure signal 1 (secondary)

ACCESSING DIAGNOSTIC TROUBLE CODES

1. Select the Diagnostics button.
2. Select the Diagnostic Trouble Codes (DTC) tab.
 - Current trouble codes appear in the Active table. The DTC Identification number and occurrence count is listed.
 - Resolved trouble codes appear in the Inactive table. The DTC Identification number and occurrence count is listed.
3. Use the up and down arrows to scroll through the list of trouble codes. A description of the highlighted code is shown below each table.
4. If desired, press the Clear button to erase all the trouble codes listed in the Inactive table.



DIAGNOSTIC TROUBLE CODES (DTC)

The table below provides the DTC number, a brief alarm description, and a possible solution.

DTC	Alarm Description	Solution
0.00	Default no error state.	No Action Required
158.03	Switched Supply Voltage High.	Check the vehicle battery to ensure power harnessing is connected to a 12 VDC battery.
158.04	Switched Supply Voltage Low.	Check the vehicle battery to ensure power harnessing is connected to a 12 VDC battery.
628.02	NVM Warning	
628.13	NVM Invalid	
628.13	NVM Error	

DTC	Alarm Description	Solution
630.13	System configuration or calibration required.	Ensure all calibration parameters have valid data.
4305.00	Application speed exceeded.	Operate at lower application speeds.
4305.02	Speed is below operational speed	Operation at higher application speeds.
520192.01	Low Current Power Loss	
520453.31	FPGA has not loaded correctly	Contact your Raven dealer or a qualified service provider.
522992.02	Scale 1 - Load cell voltage invalid	Check load cell sensor connections and cabling.
522993.02	Scale 2 - Load cell voltage invalid	Check load cell sensor connections and cabling.
522994.02	Scale 3 - Load cell voltage invalid	Check load cell sensor connections and cabling.
522995.02	Scale 4 - Load cell voltage invalid	Check load cell sensor connections and cabling.
523075.08	Implement Height Switch Malfunction	Service the Implement Height Switch.
523148.01	Valve power sense circuit 1 error	Check fuses in IBIC harness.
523149.01	Valve power sense circuit 2 error	Check fuses in IBIC harness.
523150.01	Valve power harness error	Ensure that the product harness is connected and all fuses in IBIC harness are not blown.
523160.17	Product bin/tank 1 volume has fallen below the operator designated minimum level.	Refill the bin/tank.
523196.00	Section valve master open when it should be closed	Contact your Raven dealer or a qualified service provider.
523196.01	Section valve master closed when it should be open	Contact your Raven dealer or a qualified service provider.
523200.00	Section valve 1 open when it should be closed	Contact your Raven dealer or a qualified service provider.
523200.01	Section valve 1 closed when it should be open	Contact your Raven dealer or a qualified service provider.
523201.00	Section valve 2 open when it should be closed	Contact your Raven dealer or a qualified service provider.
523201.01	Section valve 2 closed when it should be open	Contact your Raven dealer or a qualified service provider.
523202.00	Section valve 3 open when it should be closed	Contact your Raven dealer or a qualified service provider.
523202.01	Section valve 3 closed when it should be open	Contact your Raven dealer or a qualified service provider.
523203.00	Section valve 4 open when it should be closed	Contact your Raven dealer or a qualified service provider.
523203.01	Section valve 4 closed when it should be open	Contact your Raven dealer or a qualified service provider.
523204.00	Section valve 5 open when it should be closed	Contact your Raven dealer or a qualified service provider.

DTC	Alarm Description	Solution
523204.01	Section valve 5 closed when it should be open	Contact your Raven dealer or a qualified service provider.
523205.00	Section valve 6 open when it should be closed	Contact your Raven dealer or a qualified service provider.
523205.01	Section valve 6 closed when it should be open	Contact your Raven dealer or a qualified service provider.
523206.00	Section valve 7 open when it should be closed	Contact your Raven dealer or a qualified service provider.
523206.01	Section valve 7 closed when it should be open	Contact your Raven dealer or a qualified service provider.
523207.00	Section valve 8 open when it should be closed	Contact your Raven dealer or a qualified service provider.
523207.01	Section valve 8 closed when it should be open	Contact your Raven dealer or a qualified service provider.
523208.00	Section valve 9 open when it should be closed	Contact your Raven dealer or a qualified service provider.
523208.01	Section valve 9 closed when it should be open	Contact your Raven dealer or a qualified service provider.
523209.00	Section valve 10 open when it should be closed	Contact your Raven dealer or a qualified service provider.
523209.01	Section valve 10 closed when it should be open	Contact your Raven dealer or a qualified service provider.
523232.04	Pressure 1 - Sensor not detected	Check the pressure transducer connection and cabling.
523232.13	Pressure 1 - Sensor not calibrated	Calibrate the pressure sensor.
523232.16	Pressure 1 - Pressure above maximum set point	Reduce the equipment speed or adjust the maximum pressure setting.
523232.18	Pressure 1 - Pressure below minimum set point	Increase the equipment speed or adjust the minimum pressure setting.
523233.04	Pressure 2 - Sensor not detected	Check the pressure transducer connection and cabling.
523233.13	Pressure 2 - Sensor not calibrated	Calibrate the pressure sensor.
523233.16	Pressure 2 - Pressure above maximum set point	Reduce the equipment speed or adjust the maximum pressure setting.
523233.18	Pressure 2 - Pressure below minimum set point	Increase the equipment speed or adjust the minimum pressure setting.
523234.04	Pressure 3 - Sensor not detected	Check the pressure transducer connection and cabling.
523234.13	Pressure 3 - Sensor not calibrated	Calibrate the pressure sensor.
523234.16	Pressure 3 - Pressure above maximum set point	Reduce the equipment speed or adjust the maximum pressure setting.
523234.18	Pressure 3 - Pressure below minimum set point	Increase the equipment speed or adjust the minimum pressure setting.
523235.04	Pressure 4 - Sensor not detected	Check the pressure transducer connection and cabling.

DTC	Alarm Description	Solution
523235.13	Pressure 4 - Sensor not calibrated	Calibrate the pressure sensor.
523235.16	Pressure 4 - Pressure above maximum set point	Reduce the equipment speed or adjust the maximum pressure setting.
523235.18	Pressure 4 - Pressure below minimum set point	Increase the equipment speed or adjust the minimum pressure setting.
523236.04	Pressure 5 - Sensor not detected	Check the pressure transducer connection and cabling.
523236.13	Pressure 5 - Sensor not calibrated	Calibrate the pressure sensor.
523236.16	Pressure 5 - Pressure above maximum set point	Reduce the equipment speed or adjust the maximum pressure setting.
523236.18	Pressure 5 - Pressure below minimum set point	Increase the equipment speed or adjust the minimum pressure setting.
523237.04	Pressure 6 - Sensor not detected	Check the pressure transducer connection and cabling.
523237.13	Pressure 6 - Sensor not calibrated	Calibrate the pressure sensor.
523237.16	Pressure 6 - Pressure above maximum set point	Reduce the equipment speed or adjust the maximum pressure setting.
523237.18	Pressure 6 - Pressure below minimum set point	Increase the equipment speed or adjust the minimum pressure setting.
523242.01	Product Pump 1 - PWM Pump dry	Verify there is product in the tank for the pump.
523242.07	Product Pump 1 - AccuFlow HP+ boost pump fault	Contact your Raven dealer or a qualified service provider.
523242.18	Product Pump 1 - Non-PWM Pump dry	Verify there is product in the tank/bin for the pump.
523243.01	Product Pump 2 - PWM Pump dry	Verify there is product in the tank for the pump.
523243.18	Product Pump 2 - Non-PWM Pump dry	Verify there is product in the tank for the pump.
523244.01	Product Pump 3 - PWM Pump dry	Verify there is product in the tank for the pump.
523244.18	Product Pump 3 - Non-PWM Pump dry	Verify there is product in the tank for the pump.
523245.01	Product Pump 4 - PWM Pump dry	Verify there is product in the tank for the pump.
523245.18	Product Pump 4 - Non-PWM Pump dry	Verify there is product in the tank for the pump.
523246.01	Product Pump 5 - PWM Pump dry	Verify there is product in the tank for the pump.
523246.18	Product Pump 5 - Non-PWM Pump dry	Verify there is product in the tank for the pump.
523247.01	Product Pump 6 - PWM Pump dry	Verify there is product in the tank for the pump.
523247.18	Product Pump 6 - Non-PWM Pump Dry	Verify there is product in the tank for the pump.

DTC	Alarm Description	Solution
523253.17	Product 2 Injection - Pump lost communication	Check power and ISOBUS connections to the injection pump.
523254.17	Product 3 Injection - Pump lost communication	Check power and ISOBUS connections to the injection pump.
523255.17	Product 4 Injection - Pump lost communication	Check power and ISOBUS connections to the injection pump.
523256.17	Product 5 Injection - Pump lost communication	Check power and ISOBUS connections to the injection pump.
523257.17	Product 6 Injection - Pump lost communication	Check power and ISOBUS connections to the injection pump.
523262.15	RPM 1 - Above maximum threshold	Contact your Raven dealer or a qualified service provider.
523262.17	RPM 1 - Below minimum threshold	Contact your Raven dealer or a qualified service provider.
523263.15	RPM 2 - Above maximum threshold	Contact your Raven dealer or a qualified service provider.
523263.17	RPM 2 - Below minimum threshold	Contact your Raven dealer or a qualified service provider.
523285.01	Product 1 Shaft Sensor - No rate detected.	Contact your Raven dealer or a qualified service provider.
523286.01	Product 2 Shaft Sensor - No rate detected.	Contact your Raven dealer or a qualified service provider.
523287.01	Product 3 Shaft Sensor - No rate detected.	Contact your Raven dealer or a qualified service provider.
523288.01	Product 4 Shaft Sensor - No rate detected.	Contact your Raven dealer or a qualified service provider.
523289.01	Product 5 Shaft Sensor - No rate detected.	Contact your Raven dealer or a qualified service provider.
523290.01	Product 6 Shaft Sensor - No rate detected.	Contact your Raven dealer or a qualified service provider.
523295.01	Product 1 Dual Encoder - Feedback out of tolerance.	Contact your Raven dealer or a qualified service provider.
523296.01	Product 2 Dual Encoder - Feedback out of tolerance.	Contact your Raven dealer or a qualified service provider.
523297.01	Product 3 Dual Encoder - Feedback out of tolerance.	Contact your Raven dealer or a qualified service provider.
523298.01	Product 4 Dual Encoder - Feedback out of tolerance.	Contact your Raven dealer or a qualified service provider.
523299.01	Product 5 Dual Encoder - Feedback out of tolerance.	Contact your Raven dealer or a qualified service provider.
523300.01	Product 6 Dual Encoder - Feedback out of tolerance.	Contact your Raven dealer or a qualified service provider.
523305.00	Product 1 Rate - No rate expected.	Check connection to the control valve.
523305.01	Product 1 Rate - No rate detected.	Check connections to the control valve and flow sensor.
523306.00	Product 2 Rate - No rate expected.	Check connection to the control valve.

DTC	Alarm Description	Solution
523306.01	Product 2 Rate - No rate detected.	Check connections to the control valve and flow sensor.
523307.00	Product 3 Rate - No rate expected.	Check the connection to the control valve.
523307.01	Product 3 Rate - No rate detected.	Check connections to the control valve and flow sensor.
523308.00	Product 4 Rate - No rate expected.	Check the connection to the control valve.
523308.01	Product 4 Rate - No rate detected.	Check connections to the control valve and flow sensor.
523309.00	Product 5 Rate - No rate expected.	Check connections to the control valve.
523309.01	Product 5 Rate - No rate detected.	Check the connections to the control valve and flow sensor.
523310.00	Product 6 Rate - No rate expected	Check connections to the control valve.
523310-01	Product 6 Rate - No rate detected	Check the connections to the control valve and flow sensors.
524082.13	Display is not online	Check ISOBUS and power connections to the Raven Rate Control Module.
NA	Incompatible HW	
NA	Loopback test failed	
NA	Loopback test canceled	
NA	Loopback test warning	
NA	Manual bin chaining ready	
NA	Object pool will go offline	
NA	Test canceled	
NA	Product 2 Injection - Injection pressure below carrier pressure	
NA	Product 3 Injection - Injection pressure below carrier pressure	
NA	Product 4 Injection - Injection pressure below carrier pressure	
NA	Product 5 Injection - Injection pressure below carrier pressure	
NA	Product 6 Injection - Injection pressure below carrier pressure	
NA	Granular test warning	
NA	Liquid test warning	
NA	NH ₃ test warning	
NA	New blockage system detected	
NA	Product 1 Rate - Calibration required	
NA	Product 2 Rate - Calibration required	
NA	Product 3 Rate - Calibration required	
NA	Product 4 Rate - Calibration required	
NA	Product 5 Rate - Calibration required	
NA	Product 6 Rate - Calibration required	

DTC	Alarm Description	Solution
NA	New switchbox detected	
NA	Product 1 Rate - Rate above target	
NA	Product 2 Rate - Rate above target	
NA	Product 3 Rate - Rate above target	
NA	Product 4 Rate - Rate above target	
NA	Product 5 Rate - Rate above target	
NA	Product 6 Rate - Rate above target	
NA	New direct injection pump detected	
NA	Product 1 - PWM duty maximum detected	
NA	Product 2 - PWM duty maximum detected	
NA	Product 3 - PWM duty maximum detected	
NA	Product 4 - PWM duty maximum detected	
NA	Product 5 - PWM duty maximum detected	
NA	Product 6 - PWM duty maximum detected	
NA	Product 1 Rate - Rate below target	
NA	Product 2 Rate - Rate below target	
NA	Product 3 Rate - Rate below target	
NA	Product 4 Rate - Rate below target	
NA	Product 5 Rate - Rate below target	
NA	Product 6 Rate - Rate below target	
NA	Product bin/tank 1 volume has fallen below the operator designated minimum level	
NA	Product bin/tank 2 volume has fallen below the operator designated minimum level	
NA	Product bin/tank 3 volume has fallen below the operator designated minimum level	
NA	Product bin/tank 4 volume has fallen below the operator designated minimum level	
NA	Product bin/tank 5 volume has fallen below the operator designated minimum level	
NA	Product bin/tank 6 volume has fallen below the operator designated minimum level	
NA	Product 1 Rate - Volume per minute below minimum	
NA	Product 1 - PWM duty cycle minimum reached.	
NA	Product 2 Rate - Volume per minute below minimum	
NA	Product 2 - PWM duty cycle minimum reached.	
NA	Product 3 Rate - Volume per minute below minimum	

DTC	Alarm Description	Solution
NA	Product 3 - PWM duty cycle minimum reached.	
NA	Product 4 Rate - Volume per minute below minimum	
NA	Product 4 - PWM duty cycle minimum reached.	
NA	Product 5 Rate - Volume per minute below minimum	
NA	Product 5 - PWM duty cycle minimum reached.	
NA	Product 6 Rate - Volume per minute below minimum	
NA	Product 6 - PWM duty cycle minimum reached.	
NA	Product bin/tank 1 level indicated empty bin/tank	
NA	Product bin/tank 2 level indicated empty bin/tank	
NA	Product bin/tank 3 level indicated empty bin/tank	
NA	Product bin/tank 4 level indicated empty bin/tank	
NA	Product bin/tank 5 level indicated empty bin/tank	
NA	Product bin/tank 6 level indicated empty bin/tank	
NA	Blockage system offline	
NA	Product 1 Rate - Application attempted with no controlled RPM speed.	
NA	Product 1 Rate - Application attempted with no monitored RPM speed.	
NA	Product 2 Rate - Application attempted with no controlled RPM speed.	
NA	Product 2 Rate - Application attempted with no monitored RPM speed.	
NA	Product 3 Rate - Application attempted with no controlled RPM speed.	
NA	Product 3 Rate - Application attempted with no monitored RPM speed.	
NA	Product 4 Rate - Application attempted with no controlled RPM speed.	
NA	Product 4 Rate - Application attempted with no monitored RPM speed.	
NA	Product 5 Rate - Application attempted with no controlled RPM speed.	

DTC	Alarm Description	Solution
NA	Product 5 Rate - Application attempted with no monitored RPM speed.	
NA	Product 6 Rate - Application attempted with no controlled RPM speed.	
NA	Product 6 Rate - Application attempted with no monitored RPM speed.	
NA	Communication lost with switchbox	
NA	Scale 1 - Unexpected weight increase	
NA	Scale 2 - Unexpected weight increase	
NA	Scale 3 - Unexpected weight increase	
NA	Scale 4 - Unexpected weight increase	

A

SECTION WIDTHS

Use the following formulas to help calculate the section widths.

Calculate the section width with the formula:

$$T \times S = SW$$

Where T = the number of Tips in each section, S = the Spacing between tips, and SW = the Section Width.

FOR EXAMPLE:

20 tips in a section with spacing of 40 inches [50.8 cm] would yield:

$$20 \times 40 = 800$$

or a Section Width of 800 inches [2032 cm] (approximately 67 feet [20 m]). Enter 800 [2032] as the width for this section.

TARGET RATE CALIBRATION

The following information must be known in order to determine which spray nozzles to use with the sprayer:

- Nominal Application Pressure _____ PSI [kpa]
- Target Application Rate _____ GPA [lit/ha]
- Target Speed _____ MPH [km/h]
- Nozzle Spacing _____ inches [cm]

From this information, calculate the volume per minute per nozzle as follows:

$$NVPM = \frac{\text{Rate} \times \text{Speed} \times NS}{5,940[60,000]}$$

NVPM = Nozzle Volume per Minute (gallons/acre [lit/ha]), Rate = target application Rate, Speed = target Speed of application, and NS = Nozzle Spacing

FOR EXAMPLE:

Application Pressure = 30 PSI, Target Application Rate = 20 GPA, Target Speed = 5.2 MPH, and Nozzle Spacing = 20 inches

$$NVPM = \frac{20 \times 5.2 \times 20}{5,940} = 0.35$$

Using the calculated nozzle volume per minute of 0.35 at an application pressure of 30, select a boom nozzle which comes closest to providing the desired output.

APPENDIX

SETTINGS AND HELP SCREEN TERMINOLOGY

B

TABLE 1. Setting and Help Screen Terminology

Setting	Help Screen Terminology
Control Deadband	Allowable difference between the target and actual application rate. Rate correction is not performed as long as the application rate is within the allowable range.
Control Valve Type	Select the type of control valve used to control the product application. Valve types include: Standard, Fast, Fast Close, PWM, and PWM Close.
Display Smoothing	Enable the Display Smoothing feature to display target rate as actual rate when rate is within 10% of the target rate. Actual rate will be displayed if rate controller does not reach control deadband within ten seconds.
Enable Fence Rows	Enable Fence Rows if sprayer is equipped. On-screen soft switches or physical switches can be assigned to control fence row valves. Restart the setup wizard to modify this setting.
Fill Flow Meter Cal	The fill flow meter calibration value and units may be found on the tag attached to the flow meter installed in the tank fill system. Select the appropriate units for the flow meter calibration to ensure proper calibration of the tank fill system.
Flow Meter Cal	The flow meter calibration value and units may be found on the tag attached to the flow meter installed in the application system. Select the appropriate units for the flow meter calibration to ensure proper calibration of the application system.
Implement Switch	The implement switch senses the position of the toolbar and turns off application when raised and enables application when lowered.
Low Tank Limit	Enable the Low Tank feature and enter desired volume threshold at which an alert will be displayed for low tank condition. Tank volume must be either manually set upon refilling or tank fill flow meter utilized to automatically monitor tank level.
Max Pump PWM	Enter a maximum PWM duty cycle percent to set the maximum desired output for a pulse width modulated (PWM) hydraulic control valve. This setting limits how far the PWM valve will open.
Maximum Pressure	Enter the maximum desired pressure for the system. Upon exceeding maximum pressure, an alert will be displayed, flow control will be overridden and the rate controller will maintain maximum pressure.
Min Pump PWM	Enter a minimum PWM duty cycle percent to set the minimum desired output (zero point or shutoff point) for a pulse width modulated (PWM) hydraulic control valve).
Minimum Pressure	The minimum pressure feature will allow the operator to set the lowest tolerable pressure during field operations. If the application system reaches the minimum pressure, the UT will display an alert and application system will maintain the flow rate to keep the monitored pressure consistent and to maintain the spray pattern.
Number of Sections	The number of sections is the number of section valves installed on the machine.

Setting	Help Screen Terminology
Pressure Transducer Type	Select the pressure sensor range from the drop down Menu. Refer to OEM for transducer installed, or Raven part numbers.
Pressure Sensor Type	Select the pressure sensor drop down field and select the transducer to be calibrated for operation.
PWM Standby	Enter desired control valve PWM duty cycle percent when all sections are off. This is utilized when standby pressure control is not available (pressure sensor not available or direct injection is installed).
Rate Presets	Enter desired rate presets to allow the operator to quickly switch between target rates during field operation in the automatic rate control mode.
Response Rate	The response rate has a range of 1 to 100 and the setting determines how aggressively the target is controlled to. Increasing this value will cause the system to respond more quickly. Decreasing it will cause a slower response. If the system is slow to reach the target value consider increasing it.
Speed Cal	Enter the Speed Cal value of radar speed sensor (if equipped). Reference radar manufacturer's specification for recommended value and perform distance calibration to ensure accuracy.
Tank Capacity	Enter maximum capacity of the tank.
Tank Volume	Enter the current tank level.